

Operating Instructions for Non-contact Radar Level Transmitter, 80 GHz – Compact Design -

Model: NRE-4/NRE-6







We don't accept warranty and liability claims neither upon this publication nor in case of improper treatment of the described products.

The document may contain technical inaccuracies and typographical errors. The content will be revised on a regular basis. These changes will be implemented in later versions. The described products can be improved and changed at any time without prior notice.

© Copyright

All rights reserved.

1. Contents

1.	Contents	2
2.	Note	4
3.	Instrument Inspection	4
4.	Regulation Use	4
5.	Operating Principle	5
6.	Conditions for safe operation	5
	6.1 Explosion Protection, Designation, Limit Values	6
7.	Linearity error	7
8.	Integration into the technological process	7
	8.1 Level measurement applications	7
	8.2 Flow measurement applications	10
9.	Wiring	11
	9.1 Available user interfaces	13
	9.2 BUS (HART®) communication	13
	9.3 Commissioning and setting up	14
10.	. Programming	14
	10.1 Configuring the measurement	14
	10.2 Current loop output	21
	10.3 Relay output (optional)	23
	10.4 Digital communication	24
	10.5 Measurement optimization	25
	10.6 Volume measurement	28
	10.7 Open-channel flow measurement	29
	10.8 Output Conversion Table – OCT programming	33
	10.9 Service diagnostic parameters (read only)	34
	10.10 Flow measurement control parameters (read only)	34
	10.11 Output control parameters (read only)	34
	10.12 Hardware/Software versions (read only)	34
	10.13 Service functions	34
11.	. Trouble shooting	36
	11.1 Status and error indication in HART [®] communication	36
	11.2 Typical application errors	37
12.	. NUS-NTB_NRM-SW Instructions	38

	12.1	Device Status Window	38
	12.2	Echo Diagram (oscilloscope function)	38
	12.3	Threshold settings	39
	12.4	Threshold mask	40
	12.5	The output conversion table (OCT) – (NUS-NTB_NRM-SW OC-	
		Table)	41
	12.6	Programming example 1 – configuring level measurement (using NUS-NTB NRM-SW)	42
	12.7	Programming example 2 – configuring the current loop output (using	
		NUŠ-NTB NRM-SW)	43
13.	Progr	amming with NRM-300P Display Unit	43
	13.1	NRM-300P display unit	43
	13.2	The NRE-4/NRE-6 during programming	44
	13.3	Manual programming	45
14.	Parar	neter list	46
15.	Maint	enance, repair and storage conditions	47
16.	Firmv	vare update	47
17.	Tech	nical Information	48
18.	Orde	^r Codes	48
19.	Dime	nsions	48
20.	Dispo	osal	49
21.	EUD	eclaration of Conformance	50
22.	EU D	eclaration of Conformity (ATEX)	52
23.	Ex ia	Certificate	53

Manufactured and sold by:

Kobold Messring GmbH Nordring 22-24 D-65719 Hofheim Tel.: +49(0)6192-2990 Fax: +49(0)6192-23398 E-Mail: info.de@kobold.com Internet: www.kobold.com

2. Note

Please read these operating instructions before unpacking and putting the unit into operation. Follow the instructions precisely as described herein.

The instruction manuals on our website <u>www.kobold.com</u> are always for currently manufactured version of our products. Due to technical changes, the instruction manuals available online may not always correspond to the product version you have purchased. If you need an instruction manual that corresponds to the purchased product version, you can request it from us free of charge by email (<u>info.de@kobold.com</u>) in PDF format, specifying the relevant invoice number and serial number. If you wish, the operating instructions can also be sent to you by post in paper form against an applicable postage fee.

Operating instructions, data sheet, approvals and further information via the QR code on the device or via <u>www.kobold.com</u>

The devices are only to be used, maintained and serviced by persons familiar with these operating instructions and in accordance with local regulations applying to Health & Safety and prevention of accidents.

When used in machines, the measuring unit should be used only when the machines fulfil the EC machinery directive.

3. Instrument Inspection

Instruments are inspected before shipping and sent out in perfect condition. Should damage to a device be visible, we recommend a thorough inspection of the delivery packaging. In case of damage, please inform your parcel service / forwarding agent immediately, since they are responsible for damages during transit.

Scope of delivery:

The standard delivery includes:

 Non-contact Radar Level Transmitter, 80 GHz – Compact Design-Model: NRE-4/NRE-6

4. Regulation Use

Any use of the device, which exceeds the manufacturer's specification, may invalidate its warranty. Therefore, any resulting damage is not the responsibility of the manufacturer. The user assumes all risk for such usage.

5. Operating Principle

The reflection of the millimeter-waves is highly dependent on the dielectric constant of the medium. Therefore, the measured medium's dielectric constant (ϵ r) must be over 1.9 for millimeter-wave level measurement. The measurement principle of a level transmitter with a millimeter-waves signal is based on measuring the reflection's time of flight.

The speed of propagation of millimeter-waves signals in the air, gases, and vacuum is almost constant regardless of temperature and medium pressure, so the measured distance does not depend on the physical parameters of the intermediate medium.

The NRE-4/NRE-6 level transmitter is a continuous-wave frequency modulated radar (FMCW) operating at 80 GHz (W-band). The most obvious advantages of 80 GHz radars over lower frequency (5 ... 12 & 25 GHz) radars are smaller antenna size, better focus, and smaller beam angle. A portion of the millimeter-wave continuous wave energy radiated by the level transmitter antenna is reflected from the measured surface, depending on the material to be measured. The distance of the reflecting surface is calculated with high accuracy by the electronics from the frequency shift of the reflected signal and converted into a distance, level, or volume signal by the electronics.

6. Conditions for safe operation

Compliance with technological process conditions

- If the device is installed in a place subject to overvoltage, the device must be protected with at least class II surge protection!
- The device must be connected to the earth of the EP network via its earth screw.



- The cable outside of the device must be secured and unencumbered!
- The device operated from a power supply complying with Class 1 surge protection (SELV/PELV).

Compliance with local rules and regulations

The NRE-4/NRE-6 is a Local Positioning Radar (LPR) and must be mounted in a fixed, antenna-down position. In addition, the following two restrictions on antenna placement and height from the ground must be observed:

- a separation distance of 4 km (2.48 miles) from radio astronomy sites operating in the frequency band 75...85 GHz, unless specifically authorized by the ruling national regulatory authority.
- At a distance of between 4 and 40 km (2.48 and 24.8 miles) from any radio astronomy site, the height of the radar above ground level must not exceed 15 m (49.2 ft).

Compliance with Ex requirements

- Intrinsically save devices may only be operated from a circuit that complies with the technical data of the device and is marked [Ex ia IIC] or [Ex ia IIB].
- The device may contain components capable of being electrostatically charged! The presence of electrostatic charges can cause sparks and ignition, so electrostatic charges must be prevented entirely in potentially explosive (Ex) atmospheres!
- The device must only be installed in an environment that is free from direct air currents and any other charging effects. Except in the case of application group III, if the conductivity of the particulate matter is greater than >10-9 S (at 50±5% relative humidity) or >10-11 S (at 30±5% relative humidity).
- Extreme care must be taken during maintenance when there may be explosive residue in the process tank. The device may only be touched in an explosive (Ex) environment with a wet antistatic cloth!

6.1 Explosion Protection, Designation, Limit Values

6.1.1 ATEX Intrinsically Safe Protection (Ex ia) – ATEX Certificate No.: BKI24ATEX0011 X

APPLICATION GROUP		lic	III	
Standard version		NRE-xxSxxxA0I/ NRE-xxSxxxA1I		
Ex marking (ATEX)		🐼 II 1G Ex ia IIC T6 Ga	ጭ II 1D Ex ia IIIC T85°C Da	
High-temperature version		NRE-xxHxxxxxA0I/ NRE-xxHxxxxxA1I		
Ex marking (ATEX)		🐼 II 1G Ex ia IIC T6T3 Ga	🗟 II 1D Ex ia IIIC T85°C…T180°C Da	
Ex power supply,		Ui = 30 V, li = 100 mA, Pi = 0,75 W	Ui = 30 V, li = 140 mA, Pi = 1 W	
intrinsically safety data (12)		Ci ≤ 12 nF, Li ≤ 250 μH	$C_i \le 12 \text{ nF}, Li \le 250 \mu \text{H}$	
Supply voltage		1230 V DC		
Cable entry		M20×1.5 cable gland		
Electrical	Cable outer diameter	Ø612 mm (Ø0.250.5")		
connection	Wire cross-section	0.51.5 mm ² (AWG2015)		
Temperature limit data		See tables in section 3.5.2.		

(12) In IIB applications, Ex power supply data for IIIC can be used.

6.1.2 Temperature Limit Data for ATEX (Ex ia) Approved Models

Temperature data	Hazardous gas atmospheres NRE-4xSxxxA0I/ NRE-6xSxxxA0I, NRE-4xSxxxA1I/ NRE-6xSxxxA1I Ex ia IIC Ex ia IIIC	Explosive dust atmospheres NRE-4xHxxxxA0I/ NRE-6xHxxxxA0I, NRE-4xHxxxxA1I/ NRE-6xHxxxxA1I Fx ia IIC Fx ia IIIC		es xxA0l, xxA1l
Temperature class	T6	T5	T4	Т3
	T85°C	T100°C	T135°C	T180°C
Highest process temperature	+80 °C (+176 °F)	+100 °C (+212 °F)	+135 °C (+275 °F)	+180 °C (+356 °F)
Highest surface temperature at the process connection	+70 °C (+158 °F)	+100 °C (+212 °F)	+135 °C (-	+275 °F)
Highest ambient temperature	+70 °C (+158 °F)	+70 °C (+158 °F)	+60 °C (+	·140 °F)

7. Linearity error



8. Integration into the technological process

8.1 Level measurement applications

Positioning

The optimal location for NRE-4/NRE-6 (for a cylindrical tank) is at radius r = (0.3...0.5) R. It is always advisable to consider the radiation cone angle.

The liquid surface must be perpendicular to the axis of the device.

Under no circumstances place the device near the inlet opening! Improper placement may lead to malfunctions.

In the case of enclosed antenna designs, the possibility of antenna front surface humidity should be minimized.



OBSTACLES

It is essential to avoid objects (pipes, ladders, structural elements, thermometers, etc.) entering the radiation cone.

CAUTION! If necessary, programming can block up to 4 interfering echoes in the NRE-4/NRE-6 threshold settings by programming!

ALIGNMENT

The plane of the process connection must be parallel to the measured surface within $\pm 2...3^{\circ}$.

GASES / STEAM

In a closed (especially outdoors, exposed to direct sunlight) tank, vapors/gases above the liquid may reduce the millimeter-wave signal transmission.





EMPTY TANK

Especially in the case of tanks with convex or conical bottoms or tanks with equipment (e.g., heating element, mixing paddle) at the bottom, the device may indicate an incorrect level when draining completely.

It is because the tank bottom or objects at the bottom of the tank scatter or reflect the millimeter waves emitted to a certain extent, or the lower signal level of the scattered radiation interferes with itself in the tank. At least 100 mm (3.9") of liquid must cover these interfering devices or the convex or conical tank bottoms for a reliable measurement.

TEMPERATURE

The sensor must be protected from direct sunlight to avoid exceeding the highest permitted temperature.

FOAM

Foam on the measured surface may prevent millimeter-wave level measurement. The sensor should be mounted in a position below which the formation of foam is the smallest.







8.2 Flow measurement applications

The instrument can be used for open channel flow measurement with the flumes and weirs described in Chapter 10.7.

- The distance of the sensor from the surface must be adjusted, taking into account the maximum level to be measured and the proximity linearization error curve in Chapter 7.
- The sensor must be positioned on the longitudinal axis of the restricting element at a location determined by the characteristics of the restricting element. This point is marked on KOBOLD Parshall flumes.
- Foam may form on top of the flowing liquid which may affect the measurements. The liquid's surface must be exposed in front of the sensor to obtain a good echo.
- The sensor must be fixed so that it cannot move.
- The correct construction of the upstream and downstream sections of the measurement channel is of utmost importance for the accuracy of the measurement.
- The accuracy of volume flow measurement based on the level change also depends on the size and design of the restrictive element (channel or weir) used and the surface quality of the flowing liquid (ripple, foam). Therefore, flow measurement accuracy is necessarily lower than the accuracy achievable with level measurement.
- The sensor must be protected from direct sunlight by a cover to prevent the sensor from exceeding the maximum permitted temperature.

9. Wiring



1. Remove the cover of the device housing.

2. Insert the cable through the cable gland into the terminal block.

3. Strip approximately 80 mm (3.15") of the insulation of the cable and remove approximately 4 mm of the insulation of the wires. Cut the shielding of the signal cable.

4. Connect to points 2 and 3 of the terminal block according to the marked polarity.

5. Pull the cable back with about 10 mm (0.4") of the cable insulation remaining in the cable gland. Tighten the socket locking nuts with two wrenches.

6. Arrange the wiring in the housing.

7. Put the cover back on.

In non-explosive atmospheres, the device must be operated only from a galvanically isolated power supply!

For devices used in hazardous areas, the requirements in section "3.7 Conditions for safe operation" must be observed when selecting the power supply.

The insulation test with a test voltage of 500 V AC is prohibited due to the internal electronic overvoltage protection!

Connecting (grounding) to an equip (EPH)	otential network	Electrostatic Discharge (E.S.	D.)
Earthing connector (EP) on the side of the device housing, maximum conductor cross-section: 4 mm ² (AWG12). The instrument housing must be earthed to a R <1 Ω resistive earth. The shield of the measuring cable must be grounded in the instrument room. The measuring cable should not be routed near high- power cables, as shielding does not protect against switching harmonics.	EP NPT ½" M20x1.5	The device is protected against 4 kV E.S.D. Warning! The internal protection of the instrument against ESD cannot protect the entire measuring system against electrostatic discharge. In all cases, it is the user's responsibility to ensure the grounding of the tank and the measured material.	

Designing a measuring network

Power suppry	
Nominal voltage:	24 V DC
Maximum voltage (Uin):	36 V DC
Minimum voltage (Uin):	Depends on the load impedance. (See diagram)

Loop resistance, R_{loop} Minimum RA Maximum RA R_{HART} resistance for HART® communication RHART + Rcable + Rammeter 0 Ω 750 Ω

250 Ω (recommended)



Line "A": minimum voltage at the input terminals of the device

Line "B": minimum supply voltage (voltage across the device and the 250 Ω loop resistor)

Example for calculating the supply voltage:

The required minimum supply voltage at Imin = 4 mA:

 U_{supply} min. = U_{input} min. + (I_{min} * loop resistance) = 11.5 V + (4 mA * 0.25 k Ω) = 12.5 V

the required minimum supply voltage at $I_{max} = 22 \text{ mA}$:

 U_{supply} min. = U_{input} min. + (I_{min} * loop resistance) = 11.5 V + (22 mA * 0.25 k Ω) = 18.5 V. Therefore, in the case of a loop resistance of 250 Ω , the 17 V supply voltage is just sufficient for the whole 4...20 mA in the measurement range.

In hazardous areas, the data and requirements for designing the network may be different. When designing the measurement network, take into account the data and requirements in "3.5. Explosion Protection, Designation, Limit Values" and "3.7. Conditions for safe operation".



9.1 Available user interfaces

The device can be programmed using the following tools:

HART [®] USB modem (e.g. HARTCOMM)	Ordered separately. See "NUS-NTB_NRM-SW user manual."
NRM-300P display unit	Ordered separately. See Chapter 13 "Programming with NRM-300P display unit"

9.2 BUS (HART®) communication

The device can be used in two modes:

-Current loop and HART®

-Multidrop, HART® protocol

The NUS-NTB_NRM-SW software supports both modes. In accordance with the Rosemount Standard, HART® communication can be used between the NRE-4/NRE-6 as a "slave" and the HART® master as a point-to-point connection. Communication can be implemented in two modes.



9.3 Commissioning and setting up

The factory default settings are suitable for checking functionality and simple measurement tasks but the device's full potential can only be used with the correct programming tailored to the requirements of the measured process. Therefore, to get to know the operational characteristics thoroughly and solve complex measuring tasks, it is necessary to read the chapters about programming.

Caution! The instrument starts with a current consumption of 3.5 mA (parameter P12c) after power-on and, after successful initialization, maintains the set error current of 3.8 mA (see parameter P12a) at the output until the first successful measurement!

10. Programming

The HART interface of the NRE-4/NRE-6 lets the user to access and program all device parameters. The parameter set can be accessed in three ways:

-NRM-300P plug-in display unit. See Chapter 13 for manual and menu map.

-NUS-NTB_NRM-SW software. See Chapter 12 for manual.

These methods differ in many aspects. This programming guide only discusses the method involving NUS-NTB_NRM-SW. For detailed information, refer to the descriptions of the particular access methods or the user manuals.

Some rarely used parameters cannot be set directly from the graphical interface. Instead, they can be changed referring to the parameter number at the following path.

NUS-NTB-NRM-SW Advanced mode → Parameters

10.1Configuring the measurement

P00: d c b a Unit system, default units, regional parameter

FACTORY DEFAULT: 0000

If parameter P00 is changed, the device reverts the entire parameter set to the factory default values of the new unit system. Therefore, all parameters must be set again!

 a
 Mode

 0
 Normal

 1
 High-sensitivity

NRM-300P	NUS-NTB_NRM-SW
BASIC SETUP \rightarrow APPLICATION	Application \rightarrow Operating mode

b	Unit (by "c")	
Metric (EU)		Imperial (US)
0	m	ft
1	cm	inch
2	mm	inch

NRM-300P	NUS-NTB_NRM-SW
BASIC SETUP \rightarrow UNITS \rightarrow ENGINEERING UNITS	Application \rightarrow Engineering units
\rightarrow DISTANCE UNITS	

С	Regio / Unit system	Regional parameter	
0	EU / Metric	EU, United Kingdom, Albania, Andorra, Azerbaijan, Australia, Belarus, Bosnia and Herzegovina, Canada, Liechtenstein, Moldova, Monaco, Montenegro, New Zealand, North Macedonia, Norway, San Marino, Saudi Arabia, Serbia, Switzerland, Turkey, Ukraine	
1	US / Imperial	United States	
2 3	Region 2 / Metric Region 2 / Imperial	Brazil, Japan, South Korea, Taiwan, Thailand	
4 (13)	Region 3 / Metric	India, Malaysia, South Africa	
5 ⁽¹³⁾	Region 4 / Metric	Russia, Kazakhstan	

⁽¹³⁾ The accuracy of ± 2 mm is not guaranteed for Region 3 and Region 4 settings.

NRM-300P	NUS-NTB_NRM-SW
BASIC SETUP \rightarrow UNITS \rightarrow ENGINEERING SYSTEM	Application \rightarrow Calculation system

b	Unit (by "c")	
	Metric (EU)	Imperial (US)
0	m	ft
1	cm	inch
2	mm	inch

NRM-300P	NUS-NTB_NRM-SW
BASIC SETUP \rightarrow UNITS \rightarrow ENGINEERING UNITS	Application \rightarrow Engineering units
\rightarrow DISTANCE UNITS	

С	Regio / Unit system	Regional parameter
0	EU / Metric	EU, United Kingdom, Albania, Andorra, Azerbaijan, Australia, Belarus, Bosnia and Herzegovina, Canada, Liechtenstein, Moldova, Monaco, Montenegro, New Zealand, North Macedonia, Norway, San Marino, Saudi Arabia, Serbia, Switzerland, Turkey, Ukraine
1	US / Imperial	United States
2	Region 2 / Metric	Brazil Japan South Korea Taiwan Thailand
3	Region 2 / Imperial	Brazil, Supari, South Korou, Talwari, Halland
4 (13)	Region 3 / Metric	India, Malaysia, South Africa
5 ⁽¹³⁾	Region 4 / Metric	Russia, Kazakhstan

 $^{(13)}$ The accuracy of ± 2 mm is not guaranteed for Region 3 and Region 4 settings.

NRM-300P	NUS-NTB_NRM-SW
BASIC SETUP \rightarrow UNITS \rightarrow ENGINEERING SYSTEM	Application \rightarrow Calculation system

d	Temperature unit
0	۵°
1	°F

NRM-300P	NUS-NTB_NRM-SW
BASIC SETUP \rightarrow UNITS \rightarrow ENGINEERING UNITS	Measurement configuration → Temperature
→ TEMPERATURE UNITS	-

P01: d c b a Output source

FACTORY DEFAULT: 1011

If parameter P00 is changed, the device reverts the entire parameter set to the factory default values of the new unit system.

Therefore, all parameters must be set again!



NRM-300P	NUS-NTB_NRM-SW
BASIC SETUP \rightarrow APPLICATION	Application → Operating mode

b	Unit (by "c")	
Metric (EU) Impe		Imperial (US)
0	m	ft
1	cm	inch
2	mm	inch

NRM-300P	NUS-NTB_NRM-SW
BASIC SETUP \rightarrow UNITS \rightarrow ENGINEERING UNITS	Application \rightarrow Engineering units
\rightarrow DISTANCE UNITS	

С	Regio / Unit system	Regional parameter
0	EU / Metric	EU, United Kingdom, Albania, Andorra, Azerbaijan, Australia, Belarus, Bosnia and Herzegovina, Canada, Liechtenstein, Moldova, Monaco, Montenegro, New Zealand, North Macedonia, Norway, San Marino, Saudi Arabia, Serbia, Switzerland, Turkey, Ukraine
1	US / Imperial	United States
2	Region 2 / Metric	Brazil Japan South Korea Taiwan Thailand
3	Region 2 / Imperial	Brazil, Sapari, South Norca, Taiwari, Maliana
4 (13)	Region 3 / Metric	India, Malaysia, South Africa
5 (13)	Region 4 / Metric	Russia, Kazakhstan

⁽¹³⁾ The accuracy of ±2 mm is not guaranteed for Region 3 and Region 4 settings.

NRM-300P	NUS-NTB_NRM-SW
BASIC SETUP \rightarrow UNITS	Application . Coloulation quatern
\rightarrow ENGINEERING SYSTEM	$Application \rightarrow Calculation system$

d	Temperature unit
0	۵°
1	°F

NRM-300P	NUS-NTB_NRM-SW
BASIC SETUP \rightarrow UNITS \rightarrow ENGINEERING UNITS \rightarrow TEMPERATURE UNITS	Measurement configuration \rightarrow Temperature

P01: d c b a Output source

FACTORY DEFAULT: 1011

P01ba defines the source of the primary output value (HART – PV), which also defines the value transmitted on the analog current output. The device automatically selects the measurement mode according to the selected output source. The device measures the level's distance. The other quantities are calculated based on the specified tank parameters and material characteristics.

SV PV 'dc' 'ba'	Output data / measuring mode	Parameters
10	Distance	_
11	Level	P04
12	Volume	P04, P4045
13	Weight	P04, P32, P4045
14 (14)	Flow	P04, P4045, P46
15	Empty Volume	P04, P4045, P47
16 Level%		P04
17	Volume%	P04, P4045
40	TEMP	-
41	TOT1	-
42	TOT2	-

⁽¹⁴⁾ Cannot be selected in Volume (12, 17), Weight (13), and Empty Volume (15) measuring modes.

NRM-300P	NUS-NTB_NRM-SW
MEASUREMENT CONFIGURATION	
\rightarrow PV. Mode	Measurement configuration → Measurement mode
\rightarrow SV. Mode	Ŭ

Distance measurement (DIST) / Level measurement (LEV)

- DIST: Currently measured distance
- A: Shortest measurable distance (P05)
- **H:** Longest measurable distance, it is also the zero- level distance (P04)

Volume measurement (VOL)

- DIST: Currently measured distance
- A: Shortest measurable distance
- H: Zero-level distance
- **B:** Volume associated with the highest measurable level
- C: Tank's total volume



P02: d c b a Output units

FACTORY DEFAULT: 2021

The device calculates the volume, weight, and volume flow over a unit of time using a level-dependent (non-linear) function using P40 or an output correction table (OCT). This parameter also determines the unit of measure for the "Output" column of the OCT table. The TOT value in flow measurement mode totalized (total) amount flowed. The distance, level, and temperature units can be selected in parameter P00.

		Weight unit			
	a		Metric	US	
	0		kg	lb	
	1		ton	US ton	
	2		US ton	metric ton	
NRM-300P ⁽¹⁵⁾			NUS-NTB_NRM	-SW	
BASIC SETUP \rightarrow UNITS \rightarrow ENGINEERING UNITS		Measurement configuration \rightarrow Mass Units			
\rightarrow MASS UNITS					

⁽¹⁵⁾ Appears only if an output variable (PV, SV, TV, QV) is weight!

h	Volu	ume
U	Metric	US
0	liter	gallon
1	hL	ft ³
2	m ³	barrel
3	million liter (16)	million gallon (16)

(16) Use is not recommended for flow measurement (in HART transmission it can only be interpreted in conjunction with reading an applicationspecific code). Except for MGD.

NRM-300P ⁽¹⁷⁾	NUS-NTB_NRM-SW
BASIC SETUP \rightarrow UNITS \rightarrow ENGINEERING UNITS	Measurement configuration \rightarrow Volume Units
\rightarrow VOLUME UNITS	

¹⁷⁾ Appears only if PV, SV, TV, or QV is set to FLOW!

С	Time
0	Second
1	Minute
2	Hour
3	Day

NRM-300P ⁽¹⁸⁾	NUS-NTB_NRM-SW
BASIC SETUP \rightarrow UNITS \rightarrow ENGINEERING UNITS	Measurement configuration \rightarrow Time Units
\rightarrow TIME UNITS	
(18) Appears only if DV SV TV or OV is set to ELOW	

⁸⁾ Appears only if PV, SV, TV, or QV is set to FLOW!

d	TOT	
u	Metric	US
0	liter	gallon
1	hL	ft ³
2	m ³	barrel
3	million liters (19)	million gallons (19)

⁽¹⁹⁾ Use is not recommended for flow measurement (in HART transmission it can only be interpreted in conjunction with reading an application-specific code). Except for MGD.

NRM-300P ⁽²⁰⁾	NUS-NTB_NRM-SW
BASIC SETUP \rightarrow UNITS \rightarrow ENGINEERING UNITS \rightarrow TOT UNITS	Measurement configuration \rightarrow TOT Units
⁽²⁰⁾ Appears only if PV, SV, TV, or QV is set to FLOW!	

P03: Maximum sensing distance

FACTORY DEFAULT: See X_{max} + 30 cm (1 ft).

The maximum sensing distance measured from the process connection. The device evaluates level signals only within the specified distance. The maximum sensing distance is type-specific. See the X_{max} column (+30 cm [+1 ft]) of the typespecific measurement distance table below. Smaller values can be set. The minimum value is parameter P05 + 30 cm (1 ft). It is not necessary to set this parameter. The device automatically selects the detection distance based on the zero-level distance specified in P04, within the limits of P03.

Type-specific measuring distance	Minimum X _{min} ⁽²¹⁾	Maximum X _{max}
NRE-41xxR25 / NRE-41xxN25 ⁽²²⁾	0.056 m (2.2")	10 m (33 ft)
NRE-41xxR40 / NRE-41xxN40 ⁽²²⁾	0.070 m (2.75")	10 m (33 ft)
NRE-42xxR40 / NRE-42xxN40 ⁽²²⁾	0.070 m (2.75")	20 m (66 ft)
NRE-41xxR25 / NRE-41xxN25 ⁽²³⁾	0.069 m (2.7")	10 m (33 ft)
NRE-41xxR40 / NRE-41xxN40 ⁽²³⁾	0.080 m (3.15")	10 m (33 ft)
NRE-42xxR40 / NRE-42xxN40 (23)	0.080 m (3.15")	20 m (66 ft)
NRE-43xxD75 ⁽²²⁾	0.115 m (4.53")	30 m (98.5 ft)

(21) From the plane of the process connection.
 (22) NRE-4xxP, NRE-4xxV, NRE-4xxF encapsulated antenna
 (23) NRE-4xxS, NRE-4xxM, NRE-4xxK stainless steel antenna

NRM-300P	NUS-NTB_NRM-SW
MEASUREMENT CONFIGURATION →	Measurement configuration → Sensing Distance
\rightarrow SENSING DIST.	

P04: Zero-level distance (tank height – H) FACTORY DEFAULT: See Xmax in the table This parameter must always be set, except for distance measurement.

The zero-level distance (P04) is the distance between the sealing plane of the process connection and the designated zero level of the level measurement (e.g., the bottom of the tank). The device calculates the level value from the P04 value by subtracting the measured level distance. The device automatically sets the measuring distance within the maximum sensing distance (P03). The distance given here is denoted by 'H' in the figures and formulas. The maximum distance that can be measured (X_{max}) is in the measuring distance table above, depending on the selected type. The set zero-level distance can be greater than the maximum measuring distance but not exceeding 60 m (200 ft).

Since the level measured by the device is the calculated difference between the P04 set for the given application and the distance (DIST) measured by the device, it is important to specify the zero-level distance (H) accurately.

NRM-300P	NUS-NTB_NRM-SW
CALCULATION \rightarrow ZERO-LEVEL DISTANCE	Measurement configuration \rightarrow Zero-level distance

P05: Close-end blocking (dead-zone)

FACTORY DEFAULT: See X_{min} in the table

The dead-zone (starting from the process connection of the transmitter) is the range within which the device cannot measure due to its physical limitations (antenna insertion length). This is the minimum measuring distance of the device, and it is type-dependent. See the X_{min} column of the type-specific measuring distance table above. Close-end blocking is the user-defined extension of the dead zone, within which the device does not consider any echoes. This, e.g., enables the exclusion of objects interfering with the measurement close to the sensor. Close-end blocking cannot be less than X_{min}.

NRM-300P
MEASUREMENT CONFIGURATION
NEADRIOCVINIC

NUS-NTB_NRM-SW

Measurement configuration \rightarrow Minimum (P05)

P06: Far-end blocking

FACTORY DEFAULT: 0.0

In parameter P06, we can specify a level value below which the output will no longer follow any further level decrease. Far-end blocking is used when objects at the bottom of the tank (mixer, heating coil, funnel, etc.) cause measurement uncertainty within this range, e.g., because interfering echoes cannot be safely distinguished from the echoes of the measured surface. If an echo falls within the far-end blocking range (LEV < P06), the device sends a special signal and keeps the level value defined here on the output (see figure). The "Echo in far-end blocking range" flag (see Chapter 11.1) indicates that the echo is in the far-end blocking zone. Regardless of this, the "VALID" flag is active, but the "HOLD" flag remains inactive. Far-end blocking can be deactivated with P06 = 0. Min. value: 0 / max. value: P04 – P05 – 5 cm (2")

A.) Level or volume measurement

->

- If the level drops below the value of P06:
 It keeps a level value corresponding to P06 on the output and calculates the derived values from it.
- If the level goes above the far-end blocking limit: In level or volume measurement mode, the programmed tank dimensions are valid, so farend blocking does not affect the measured or calculated values.



B.) Open-channel flow measurement

Far-end blocking is usually applied to those low-level values, below which exact volume flow cannot be calculated.

- If the level in the flume drops below the blocking value:
 - The current loop output holds the value corresponding to Q = 0.
 - For 0-value transmission via HART "No Flow" or for displaying 0.

• If the level in the flume rises above the blocking value:

Flow value is calculated using the parameters specified in the program, so remote blocking does not affect measured values.





10.2Current loop output

P08: Manual output current value

FACTORY DEFAULT: 4.0

If the analog current loop output mode (P12b) is set to "Manual," the output current takes the value specified here, and the analog transmission switches off. A value between 3.8...20.5 mA is specified in this parameter. Caution! The device automatically switches to "Manual" current output mode when a new value is set in parameter P08. When 0 is entered, the device switches to "Automatic" current transmission mode (P12b = 0) and resets the value of parameter P08 to the factory setting. In HART multi-drop mode (see parameter P19), the current loop output is fixed at 4 mA, as per standard, and the manual output current value (P08) does not apply.

NRM-300P	NUS-NTB_NRM-SW
$\begin{array}{l} \textit{OUTPUT SETUP} \rightarrow \textit{ANALOG OUTPUT} \rightarrow \\ \rightarrow \textit{FIX CURRENT VALUE} \end{array}$	Current output \rightarrow Fix output current (P08)

P10: The value of the transmitted quantity as signed to 4 mA output current FACTORY DEFAULT: 0.0 In the case of "Automatic" mode of the analog current output, it is the PV value assigned to 4 mA (usually the lower limit of the measuring range in the case of level measurement). The device scales the (HART – PV, see P01) output value to the analog current output 4...20 mA range using the values specified in parameters P10 and P11.

NRM-300P	NUS-NTB_NRM-SW
OUTPUT SETUP \rightarrow ANALOG OUTPUT \rightarrow \rightarrow PV VALUE OF 4 mA	Current output \rightarrow Assignment of 4 mA - PV

P11: The value of the transmitted quantity assigned to 20 mA output current FACTORY DEFAULT: Xmax

(See table of P03)

In the case of "Automatic" (current transmission) mode of the analog current output, it is the PV assigned to 20 mA (usually the upper limit of the measurement range in the case of level measurement). The device scales the (HART – PV, see P01) output value to the analog current output 4...20 mA range using the values specified in parameters P10 and P11. The values can be assigned inversely. (For example, 4 mA to 1 m [3.3 ft] level and 20 mA to 10 m [33 ft] level, or vice versa 20 mA to 1 m [3.3 ft] level and 4 mA to 10 m [33 ft] level.)

→ Assignment of 20 mA - PV



A: Shortest measurable distance

D: P10, P11 diagram valid for factory default settings

→ PV VALUE OF 20 mA

P12: - c b a Analog current loop output mode

FACTORY DEFAULT: 0000 Error current mode: the device indicates the error state on the current output according to the setting below. The error indication set as below persists until the error is cleared.

a	Error current mode
0	HOLD (holding last valid value)
1	3.8 mA
2	22 mA

NRM-300P	NUS-NTB_NRM-SW
OUTPUT SETUP \rightarrow ANALOG OUTPUT \rightarrow	Current output \rightarrow Error indication by the current
\rightarrow ERROR MODE	output

Analog current output mode:

b	Analog current output mode	Description	
0	Automatic (current transmission)	The value of the output current is calculated from the measured value using the parameters P10 and P11. The output of the transmitter is active.	
1	Manual	The value of the output current is not calculated from the measured value. Instead, a fixed output current (P08) is sent to the output. In this mode, the setting of the fault current mode is irrelevant. Multi-drop HART communication mode 4 mA (P19) override!	

NRM-300P	NUS-NTB_NRM-SW
OUTPUT SETUP \rightarrow ANALOG OUTPUT $\rightarrow \rightarrow$ CURRENT MODE	Outputs \rightarrow Current generator mode

Startup mode: when switching on or restarting after a power failure the current is transmitted until the device starts measuring. It is recommended to set it to the fault current of the system. For periodic applications, e.g., battery operation, selecting the "Fast" recovery mode is recommended to shorten the measurement cycle time.

	С	Initial current	Resume time [s]
	0	< 3.8 mA (Normal)	1216 ⁽²⁴⁾
ſ	1	> 22 mA (Fast)	34 ⁽²⁴⁾

(24) Depending on the radar parameters. Note that it also depends on the conditions of use and how long after resuming operation the instrument will find an echo that can be evaluated.

NRM-300P	NUS-NTB_NRM-SW
BASIC SETUP \rightarrow STARTUP CURRENT	$Outputs \rightarrow Startup current$

10.3 Relay output (optional)

P13: - c b a Relay function

FACTORY DEFAULT: 0001

а	Operating mode	Description
0	By PV (P14-P15-P16)	
1	"No ECHO" (echo loss): C1 = "On" (release)	The operating mode of the RELAY optionally built into the device can be set with this parameter. If it is set to "by PV," the RELAY operates based
2	"No ECHO" (echo loss): C2 = "On" (energize)	on the triggering (P14) and releasing (P15) values set. The "No ECHO" setting enables a switched (relay contact) error signal to the process controller. Caution! When the device is de-energized, the relay releases, so is ON.
3	FLOW impulse (P17)	
4	C1 error (release)	
9	OFF	

NRM-300P	NUS-NTB_NRM-SW
$OUTPUT SETUP \rightarrow RELAY OUTPUT \rightarrow$ $\rightarrow RELAY MODE$	Outputs \rightarrow Relay output \rightarrow Relay mode

Operating mode: only relevant for operation by PV (P13a = 0)

b	Function		Programmable parameters	Description
0	Hysteresis	P14 P15 Time Relay De-energized: ∑	P14, P15 At least 20 mm (0.787") hysteresis required between P14 and P15. P14 > P15 – normal operation P14 < P15 – inverted operation	The basic switching method of the
1	Window comparator	P14 P15 Time Energized: D S C2 C1	P14, P15 At least 20 mm (0.787") hysteresis required between P14 and P15. P14 > P15 – normal operation P14 < P15 – inverted operation	adjusted.

NRM-300P	NUS-NTB_NRM-SW
$OUTPUT SETUP \rightarrow RELAY OUTPUT \rightarrow RELAY$	Outputs \rightarrow Relay Function
FUNCTION	

FLOW impulse constant's (P17) unit (if P13:a = 3):

С	Metric (EU)	Imperial (US)
0	m ³	ft ³
1	liter	US gallon
2	liter	GB gallon

NRM-300P	NUS-NTB_NRM-SW
$\begin{array}{l} \textit{OUTPUT SETUP} \rightarrow \textit{RELAY OUTPUT} \rightarrow \\ \rightarrow \textit{VOLUME/PULSE UNIT} \end{array}$	Outputs \rightarrow Relay output \rightarrow Relay parameters \rightarrow \rightarrow Pulse constant unit

P14: Relay parameter – Relay on value

FACTORY DEFAULT: 0

The measured PV value at which reaching the upper limit value is indicated on the RELAY output. Adjustable value range: Value is adjustable according to PV setting range.

NRM-300P	NUS-NTB_NRM-SW
$\begin{array}{l} OUTPUT SETUP \rightarrow RELAY \ OUTPUT \rightarrow \\ \rightarrow ENERGIZED \ VALUE \end{array}$	Outputs \rightarrow Relay output \rightarrow Relay parameters \rightarrow Energized value

P15: Relay parameter - Relay off value

FACTORY DEFAULT: 0

The measured PV value at which reaching the lower limit value is indicated on the RELAY output. Adjustable value range: Value is adjustable according to PV setting range.

NRM-300P	NUS-NTB_NRM-SW
$\begin{array}{l} \textit{OUTPUT SETUP} \rightarrow \textit{RELAY OUTPUT} \rightarrow \\ \textit{DEENERGIZED VALUE} \end{array}$	Outputs \rightarrow Relay output \rightarrow Relay parameters \rightarrow De- Energized value

P16: Relay parameter - Relay delay

FACTORY DEFAULT: 0 If the PV measurement value has reached the lower or upper switching value or an error has occurred in the case of an error signal, the actual RELAY operation is activated after this time, or after this time, a change is visible on the output. Adjustable value range: 0...999 s.

NRM-300P	NUS-NTB_NRM-SW
$OUTPUT SETUP \rightarrow RELAY OUTPUT \rightarrow DELAY$	Outputs \rightarrow Relay delay time

P17: Relay parameter – Flow parameter value

FACTORY DEFAULT: 1 In the case of FLOW, the relay gives a pulse per volume unit specified here. The volume unit is set in parameter P13:c. The pulse width is 100 ms. The guaranteed maximum pulse density: < 3 seconds.

NRM-300P	NUS-NTB_NRM-SW
OUTPUT SETUP → RELAY OUTPUT → VOLUME/PULSE VALUE	Outputs \rightarrow Relay output \rightarrow Relay parameters \rightarrow Pulse constant

10.4Digital communication

P19: FACTORY DEFAULT: 1 HART short address (device address) A unique device address by which the device is identified and managed via HART.

а	Description
0	Analog current loop output is active (current transmission via 420 mA)
115	Analog current loop inactive (no current transmission, fixed 4 mA), multi-drop

NRM-300P	NUS-NTB_NRM-SW
$\begin{array}{l} OUTPUT SETUP \rightarrow DIGITAL OUTPUT \rightarrow \\ \rightarrow ADDRESS \end{array}$	Device Identification \rightarrow HART Device Short Address

10.5Measurement optimization

P20: Damping time

FACTORY DEFAULT: 40 Damping time reduces unwanted fluctuations in displaying the measured data (e.g., ripples). If the level jumps, the transmitted value reaches 98% of the jump at this time. Unit: second (s). Value range: 0...999 s.

	For testing	Recommended
Barely or non-volatile/waving media	0 s	8 s
Highly volatile / strongly waving liquid	>24 s	>40 s

NRM-300P	NUS-NTB_NRM-SW
MEAS. OPTIMIZATION → DAMPING TIME	Measurement optimalization \rightarrow Damping time



P22: User slope correction factor (actual/measured) FACTORY DEFAULT: 1.0 It corrects the transmitted quantity according to the distance. If the value measured by the device differs from the value under real conditions, this multiplier can be used to refine the result. The output value is multiplied by the number set here. By default, the multiplier (1) does not modify the output. Value range: 0.7...10

NRM-300P	NUS-NTB_NRM-SW
$CALCULATION \rightarrow USER SLOPE MULTIPLIER$	Measurement optimalization → Velocity user correction factor

P25: --- a Echo selection

FACTORY DEFAULT: 00

The parameter P25a sets the echo selection strategy. Automatic operating mode is suitable for most applications. For special application requirements, a specific echo selection can be set as required.

а	Echo selection within measuring window	
0	Automatic	
1	First	
2	Second	
3	Largest	
4	Last	

NRM-300P	NUS-NTB_NRM-SW
MEAS. OPTIMIZATION \rightarrow ECHO SELECTION	Measurement optimalization \rightarrow Echo selection \rightarrow \rightarrow Selection of Echo

P26/P27: Level tracking speed

FACTORY DEFAULT: 600 m/h (1 970 ft / h)

The level tracking speed is the fastest level change speed that the device can continuously track. The device will only follow a level change slower than the set value. If the device senses a level signal change faster than this value, it assumes it is the result of a measurement error (e.g., condensation), it will not accept it, and the outputs will show the last valid value. Suppose this resulted from an incorrect measurement, and the result of the next measurement is plausible based on the set maximum speed. Then hold is cancelled, and the actual measured level takes effect. If the rapid change in level was actually real, the device recalculates with each measurement whether the currently measured level is within the range determined by the product of the tracking speed and the elapsed time. If it is within the range, it cancels the hold, and the output adjusts to the new value according to the set damping parameter. Setting the level tracking speed is important when technological processes, especially during filling or discharging, produce interfering factors (e.g., ripples, foaming) that affect measurement stability. The set level tracking speed must be higher than the maximum filling/discharging speed prescribed by the technology. By entering it correctly, measurements during filling and discharging become more reliable. Caution! In tanks with a conical or pyramidal bottom, the level change rate at the bottom of the tank increases significantly due to the shape of the tank.

In this parameter pair, the filling and discharging speed can be set separately:

- P26 Level rising rate (filling speed)
- P27 Level descent rate (emptying speed)

The parameter's unit of measure: metric: [m/h]; US: [ft/h].

NRM-300P	NUS-NTB_NRM-SW
MEAS. OPTIMIZATION \rightarrow LEVEL TRACK	Measurement optimalization \rightarrow Level \rightarrow
$SPEED \rightarrow FILLING SPEED \rightarrow$	\rightarrow Level elevation rate (filling speed)
\rightarrow EMPTYING SPEED	Level descent rate (emptying speed)

NRM-300P		NUS-NTB_I
0.4.1 OLUL AT10.1.1		

FACTORY DEFAULT: 0.0

management \rightarrow Error delay

P29: Tank full limit As with P06, the echo is tracked below the specified distance, but the output is not tracked and a "Tank Full" flag is displayed. Value range: 0... (P04 – 5 cm [2"]) If P29 is less than P05, the Tank Full Limit parameter is disabled.

Measurement optimalization → Measurement loss

NUS-NTB NRM-SW

P32:

FACTORY DEFAULT: 1.0 Specific density of the measured medium If the device is set to weight transmission, the specific density of the material (medium) stored in the tank must be entered here for the weight calculation. The value is a relative ratio number (without a unit) compared to the density of water, i.e., 1 g/cm3.

Value range: 0.01...10

MEAS. OPTIMIZATION \rightarrow ECHO LOSS HANDLING

NRM-300P	NUS-NTB_NRM-SW
$CALCULATION \rightarrow SPECIFIC GRAVITY$	Measurement optimalization \rightarrow Specific gravity

NRM-300P

 \rightarrow OUTPUT HOLD TIME

P28:	ba Meası	urement loss handling
Echo I	loss handli	ng:
		Echo Jose (#

Error indication delay:

	3	
а	Echo loss ("no-Echo") handling	
0	Hold for the period in the P28b decade.	
1	Hold (indefinitely)	
2	Filling simulation (at detected speed)	
3	Filling simulation (at P26/P27 maximum speed)	
4	Tank empty (DIST = maximum / LEV = 0)	
5	Tank full (DIST minimum / LEV = maximum)	

error signal is set to a lower (3.8 mA) or upper (22 mA) error current.

1		
	NRM-300P	NUS-NTB_NRM-SW
	MEAS. OPTIMIZATION \rightarrow ECHO LOSS HANDLING	Measurement optimalization → Measurement loss
	$\rightarrow OUTPUT MODE$	management → Echo loss handling

delay.		
b	Error indication delay	Notes
0	No delay	During a short echo loss, the last value is held in transmission for a period set in P28:b. After that, it is transmitted via HART on bit 0 of DSE ⁽²⁵⁾ according to P12:a on the current loop output.
1	10 s	Measured value Held value (P28:b) Error code 2
2	20 s	HART Time
3	30 s	NOECHO Indicator
4	1 min	Echo loss appears here
5	2 min	Error current 22 mA (P12a= 2) Time
6	5 min	Current Output Measured value Held value (P28:b) Holding last value (P12a= 0) Time
7	15 min	Error current 3.8 mA (P12a= 1) Time
(25) DSE – "Dev	vice Specific Error" indicator bits (HART,). See Chapter 11 Troubleshooting.

This parameter defines the time elapsed between the occurrence of the error and the issued error signal (error current). During the delay, the output is holding the last valid measured value. The function is available for current output only if the

When the error is gone, the device returns to measuring mode after the set

FACTORY DEFAULT: 0010

P34: Threshold offset

FACTORY DEFAULT: 0 It is used for simple relative modification of the acceptance threshold value set in the Echo diagram, the value range of which is -4000...+4000. It can increase (positive value) or decrease (negative value) the device's noise suppression ability compared to the default setting. If the value is 0, there is no change compared to the set threshold value. (See Chapter 12.4 Threshold mask).

NRM-300P	NUS-NTB_NRM-SW	
MEAS. OPTIMIZATION \rightarrow THRESHOLD OFFSET	Measurement optimalization → Threshold offset	

10.6Volume measurement

P40: 0 - - b a Output value calculation method FACTORY DEFAULT: 0000 A selection of typical tank shapes for volume measurement. The tank dimensions can be set using parameters P41...P45 (see figures below). In the case of the OCT setting, the tank shape must be specified in a table.

ba	Tank shape	Parameters
	Output Conversion Table (OCT)	See Chapter 12.5
b0	Vertical cylindrical tank with a convex bottom	P40+(b), P41
01	Vertical cylindrical tank with a conical bottom	P41, P43, P44
02	Vertical rectangular tank with a pyramidal bottom	P41, P42, P43, P44, P45
03	Horizontal cylindrical tank P40(b), P41, P4	
04	Spherical tank	P41

NRM-300P	NUS-NTB_NRM-SW	
CALCULATION \rightarrow TANK SHAPE	Tank/Silo parameters → Tank shape	

b	Tank bottom shape	
0	Planar	Associating typical tank bottom shapes for the specific tank type to
1	Slightly convex	calculate the volume accurately. The exact form of the setting code
2	Strongly convex	can be seen in the drawings under parameters P4145.
3	Hemispherical	

NRM-300P	NUS-NTB_NRM-SW	
$CALCULATION \rightarrow TANK SHAPE$	Tank/Silo parameters → Bottom shape	

P41-45: ---- Tank dimensions

These are the size parameters for the tank shape selected in parameter P40 according to the dimensions shown in the drawings below. For proper operation, it is important to specify these dimensions accurately.



P47: - - - a Total tank volume

FACTORY DEFAULT: 0.0

The total tank volume is required for empty volume calculation (see parameter P01).

If one of the outputs (PV, SV, TV, or QV) is set to transmit "Ullage volume," then the total volume can be entered in this parameter to calculate the actual transmitted value. In this case, the transmitted data is the difference between the total volume and the actual medium volume. Its unit is the volume unit set in the P01b decade. Value range: 0...999,999.

NRM-300P	NUS-NTB_NRM-SW
CALCULATION \rightarrow TANK SHAPE	Tank/Silo parameters → Total tank volume

10.7 Open-channel flow measurement

P40: 0 - b a Volume flow measu rement options

FACTORY DEFAULT: 0000

ba		Flume, formula, data			Parameters		
		Output Conversion Table, See Chapter 12.5					
		Туре	Calculation formula	Q _{min} [l/s]	Q _{max} [l/s]	"P" [cm]	
00	les	GPA-1P1	Q [l/s] = 60.87*h ^{1,552}	0.26	5.38	30	P46
01	flun	GPA-1P2	Q [l/s] = 119.7*h ^{1,553}	0.52	13.3	34	P46
02	all	GPA-1P3	Q [l/s] = 178.4*h ^{1,555}	0.78	49	39	P46
03	arsh	GPA-1P4	Q [l/s] = 353.9*h ^{1,558}	1.52	164	53	P46
04	DB	GPA-1P5	Q [l/s] = 521.4*h ^{1,558}	2.25	360	75	P46
05	Ы	GPA-1P6	Q [l/s] = 674.6*h ^{1,556}	2.91	570	120	P46
06	B	GPA-1P7	Q [l/s] = 1014.9*h ^{1,56}	4.4	890	130	P46
07	×	GPA-1P8	Q [l/s] = 1368*h ^{1,5638}	5.8	1208	135	P46
08		GPA-1P9	Q [l/s] = 2080.5*h ^{1,5689}	8.7	1850	150	P46
09		Generic Parshall flume			P46, P42		
10		Palmer-Bowlus (D/2)			P46, P41		
11		Palmer-Bowlus (D/3)			P46, P41		
12		Palmer-Bowlus (rectangular)			P46, P41, P42		
13		Khafagi-Venturi			P46, P42		
14		Weir			P46, P42		
15			Rectangular o	or Bazin weir			P46, P41, P42
16		Trapezoidal weir			P46, P41, P42		
17	Special trapezoidal (4:1) weir			P46, P42			
18	V-shaped weir			P46, P42			
19	Thomson (90°) weir			P46			
20	Circular weir			P46, P41			
21	Generic formula: Q[l/s] = P41*h ^{P42} , h [m]			P46, P41, P42			
22	Generic formula: Q[l/s] = P41 *h ^{P42} , h [P00:cb]			P46, P41, P42			

P40: 0 - b a Volume flow measurement options (continued)

ba	Flume, formula, data	Parameters
30	4" Palmer-Bowlus (D/2)	P46
31	6" Palmer-Bowlus (D/2)	P46
32	8" Palmer-Bowlus (D/2)	P46
33	10" Palmer-Bowlus (D/2)	P46
34	12" Palmer-Bowlus (D/2)	P46
35	15" Palmer-Bowlus (D/2)	P46
36	18" Palmer-Bowlus (D/2)	P46
37	21" Palmer-Bowlus (D/2)	P46
38	24" Palmer-Bowlus (D/2)	P46

NRM-300P	NUS-NTB_NRM-SW
CALCULATION \rightarrow FLOW MEASUREMENT	Flow measurement → Open channel flow measurement methods

P41-45: Flume / weir dimensions

FACTORY DEFAULT: 0



		7
P40= 10	Palmer-Bowlus (D/2) flume Q [m³/s] = f(h1/P41) * P41 ^{2,5} , where h1[m] = h+(P41/10) P41 [m]	P04 P41 D/2 D/2 D/10
P40= 11	Palmer-Bowlus (D/3) flume Q [m ³ /s] = f(h1/P41) * P41 ^{2,5} , where h1[m]= h+(P41/10) P41 [m]	
P40= 12	Palmer-Bowlus (rectangular) flume Q [m ³ /s] = C*P42*h ^{1.5} , where C = f(P41/P42) P41 [m], P42 [m]	P41 P41 D/10
P40= 13	Khafagi-Venturi flume Q [m ³ /s] = 1,744 •P42 • h ^{1,5} + 0,091 • h ^{2,5} P42 [m] h [m]	PiloTREK PiloTREK PiloTREK P46 → h
P40= 14	Weir 0,0005 < Q [m ³ /s] < 1 0,3 < P42 [m] < 15 0,1 < h [m] < 10 O [m ³ /c] = 5 072 + P42 + b15	P42

	0,1 < h [m] < 10 Q [m³/s] = 5,073 · P42 · h ^{1,5} Accuracy: ±10%		
P40= 15	Rectangular or Bazin weir 0,001 < Q [m³/s] < 5 0,15 < P41 [m] < 0,8 0,15 < P42 [m] < 3 0,015 < h [m] < 0,8 Q [m³/s] =1,77738(1+0,1378h/P41) · P42 · (h+0,0012) ^{1,5} Accuracy: ±1%	P04 P46 P46	P42

P40= 16	Trapezoid weir $0,0032 < Q [m^3/s] < 82$ $20 < P41[^o] < 100$ 0,5 < P42 [m] < 15 0,1 < h [m] < 2 $Q [m^3/s] = 1,772 \cdot P42 \cdot h^{1,5} + 1,320 \cdot tg(P41/2) \cdot h^{2,47}$ Accuracy: $\pm 5\%$	98 h h pa
P40= 17	Special trapezoid (4:1) weir 0,0018 < Q [m ³ /s] < 50 0,3 < P42 [m] < 10 0,1 < h [m] < 2 Q [m³/s] = 1,866 · P42 · h ^{1,5} Accuracy: ±3%	Signature and a second
P40= 18	V-shaped weir 0,0002 < Q [m ³ /s] < 1 20 < P42[°] < 100 0,05 < h [m] < 1 Q[m ³ /s] = 1,320 · tg(P42/2) · h ^{2,47} Accuracy: ±3%	Ba h h h h h h h h h h h h h h h h h h h
P40= 19	THOMSON (90°) weir 0,0002 < Q [m ³ /s] < 1 0,05 < h [m] < 1 Q [m ³ /s] = 1,320 • h ^{2,47} Accuracy: ±3%	

P40= 20	Circular weir $0,0003 < Q [m^3/s] < 25$ 0,02 < h [m] < 2 $Q[m^3/s] = m*b \cdot D^{2.5}$, where $b = f (h/D)$ $m = 0,555+0,041 \cdot h/P41+(P41/(0,11 \cdot h))$ Accuracy: $\pm 5\%$	
P40=21	Generic formula: Q [l/s] = P41*h ^{p42} h [m]	
P40=22	Generic formula: Q [l/s] = P41*h ^{p42} 'h' will be substituted in the unit set in P00c and P00b.	
P40=3038	Palmer-Bowlus standard D/2 flume (4" 24") Refer to flume's user manual for details. P46 [P00c, P00b]	

P46: --- a Distance associated with h=0 when measuring flowFACTORY DEFAULT: VARIES BY TYPEP46 is the distance between the sensor's process connection and the liquid'ssurface, which can be measured at the limit of the start of the flow (Q = 0); seefigures. Minimum value: P05 + 5 cm (2"). Maximum value: P03.

10.8Output Conversion Table – OCT programming

P40: d - [] [] OCT operation

FACTORY DEFAULT: 0

d	Output data Measurement mode	Reference
0	Output Conversion Table OFF	See Chapter 12.5
1	Output Conversion Table ON	

An output signal of any characteristic can be assigned to the level values measured by the device. The unit of the output signal is the unit set in parameter P00 or P02 of the output data type assigned to the "HART - PV" output in parameter P01. The characteristic can be specified with a maximum of 100 points. Between the points, the device calculates the output signal from the measured level by linear interpolation and after the last point by linear extrapolation. The OCT can be used to assign the measured level to an arbitrary output signal. Its typical application is the calculation of level to volume for tanks that are not included in the tank shape list (e.g., dented) and specifying individual channel characteristics in the case of open channel flow measurement.

NRM-300P	NUS-NTB_NRM-SW
$CALCULATION \rightarrow OCT TABLE$	OC-Table \rightarrow Linearization (See Chapter12.5)

Conditions for correct programming of data pairs

- The table must start with L(1)= 0 and R(1)= is the output quantity assigned to it.
- Column "L" may not contain identical values.
- Columns "L" and "R" can only have increasing values from top to bottom.
- If the table contains less than 100 points, column "L", in the row following the last valuable data pair, must be 0.

i	L (left column) MEASURED LEVEL	R (right column) OUTPUT VALUE
1	0	R(1)
2	L(2)	R(2)
	L(i)	R(i)
nn	L(nn)	R(nn)
nn+1	0	
100		

NRM-300P	NUS-NTB_NRM-SW
$CALCULATION \rightarrow OCT TABLE$	OC-Table \rightarrow OCT list (See Chapter 7.5)

10.9 Service diagnostic parameters (read only)

P60:	 Number of operating hours since issuing [h]
P61:	 The number of operating hours since the last power-on [h]
P62:	 The number of operating hours of the relay (closed time of contact C2) [h]
P63:	 The number of switching cycles of the relay
P64:	 The current temperature of the device's electronics [°C / °F]
P65:	 The highest temperature of the device ever measured [°C / °F]
P66:	 The lowest temperature of the device ever measured [°C / °F]
P70:	 Number of detected peaks (current)
P71:	 Magnitude of selected echo (raw value)
P72	 The amplitude of the selected echo [dB]
P73:	The distance of the selected echo [m]
P74:	Echo lost/shot ratio

10.10 Flow measurement control parameters (read only)

P72		Measuring height of the flow measurement ("h" value)
	Ме	asuring height required for flow measurement. This value is the "h" value in the
	flov	w calculation formula. (See P46).

P77: ---- TOT1 totalizer (can be cleared)

P78: ---- TOT2 totalizer

10.11 Output control parameters (read only)

- P79: ---- Current generator re-measured output current [µA]
- P80: ---- Current generator calculated output current [mA]
- P81: ---- Relay output status

10.12 Hardware/Software versions (read only)

P94/95	Software code 2	/ 3 (SLAVE MCUs)
--------	-----------------	------------------

P96: ---- Software code 3 (MAIN MCU)

```
P97/98: ---- Hardware identification code
```

10.13 Service functions

10.13.1 Security codes

Enter and unlock the user code. The unit can be protected against unauthorized reprogramming by a four-digit pin code. If a value other than zero is entered, the code is active. Entering a zero will clear the user code! When the code is active, the unit will prompt for the code when entering the menu.

NRM-300P	NUS-NTB_NRM-SW
SERVICE \rightarrow SECURITY \rightarrow USER LOCK	Advanced \rightarrow Special

Current output test 10.13.2

P80: Loop current test (mA)

When the function is entered, the current value corresponding to the current being measured is displayed and output. In test mode, any value between 3.9 and 20.5 mA can be entered in this edit window. The output should then display the same current as the set value. A dialog box reminds you of the test condition. The test value will remain at the output until the warning window is exited. To exit the warning window, press E.

NRM-300P	NUS-NTB_NRM-SW
SERVICE \rightarrow OUTPUT TEST \rightarrow ANALOG OUT	PUT —

Simulation method

No simulation

Triangular symbol

10.13.3 Simulation

This function helps the user to check the outputs and the processing device connected to it. NRE-4/NRE-6 can simulate a constant or a variable value of the level. The

simulation level values must be within the measurement range defined by P04 and P05. To start the simulation, return to the Measurement mode. During simulation, the DIST, LEV or VOL symbols will flash. To end the simulation, set P84= 0.

P84: ---a Simulation method

а

0

1



	2	Simulate constant level: PV = va					
	3	Simulation between levels P86, P87 with	P86	-			
	4	Simulation between levels P86, P87 with		P85	t[sec]		
	NR	M-300P	NUS-NTB_NRM-SW				
	SE	RVICE \rightarrow DIST. SIMULATION	Advanced → Special				
P85:	85: DIST simulation cycle time					FACTORY DEFAULT	: 0
Simula	imulation cycle time. Unit of measurement: seconds [s].						

P86: Lower level of simulation **FACTORY DEFAULT: 0** Unit of measurement: according to P00b. **FACTORY DEFAULT: 0** P87: Top level of simulation Unit of measurement: according to P00b. **FACTORY DEFAULT: 10** P88: Total simulation time (timeout)

The simulation mode is automatically switched off after the value set here has elapsed. Unit of measurement: minutes [min]. Value range: 0...9999 min. The default value is 10 minutes.

10.13.4 Load default setting

Restores the factory settings of the unit. The values can then be modified. Loading the factory settings does not affect the measurement running in the background (it continues with the parameters set before entering the programming). Before loading the factory settings, the instrument displays a dialog box asking if you are sure you want to do this, because all user settings will be lost!

NRM-300P	NUS-NTB_NRM-SW
SERVICE \rightarrow DEFAULTS \rightarrow LOAD DEFAULT	Advanced \rightarrow Parameters \rightarrow Load default

10.13.5 Restart

Restarting the device "Warm start". (Reloading parameters from the non-erasing memory.)

NRM-300P	NUS-NTB_NRM-SW
SERVICE \rightarrow RESTART	Advanced \rightarrow Special

11. Trouble shooting

11.1 Status and error indication in HART[®] communication

Status and error indication in HART communication: The response code, according to the HART standard, is two 16-bit words after the "Response code" bytes, respectively "Errors and Warnings" and "Status."

Bit №	Device Specific Error/Warning flags	Meaning, possible reason, solution
0	No echo (<i>Warning</i>)	The device cannot detect the surface to be measured, so there is no echo or there are too many echoes due to interference. Ensure proper installation! If the problem persists, contact the dealership.
1	EEPROM is not detected (Error)	The parameter memory of the device is compromised. Contact dealership.
2	EEPROM checksum error detected (Error)	Some data stored in the device's parameter memory has been corrupted. Factory default settings are restored by the device. If the device's parameter memory fails frequently, contact the dealership.
3	OCT input side integrity error (<i>Error</i>)	The data in the left (L) column of the Output Conversion Table (OCT) is not incremental. Correct it.
4	OCT output side integrity error (Error)	The data in the right (R) column of the Output Conversion Table (OCT) is not incremental. Correct it.
5	OCT item count is <2 (<i>Errol</i>)	Too few points are entered into the Output Conversion Table (OCT). At least two ($i \ge 2$) points (elements) must be entered.
6	Input level over the OCT input side (overload) (Warning)	The measured level, as the input value of the OCT, points out of the range entered in the left (L) column of the OCT. Enhance the range.
7	EEPROM reinitiated (EEPROM layout damaged or missing) (<i>Error</i>)	The data structure stored in the device's parameter memory is corrupted. The device restored the factory default settings. If the device's parameter memory fails frequently, contact the dealership!
8	—	-
9	Tank full (Warning)	The measured surface is too close, within the device's minimum measuring range (X_{min}). Set the close-end blocking (P05) to a smaller value, or change the technology to ensure that the surface to be measured does not come so close to the sensor of the device.
10	Echo in far blocking range (Warning)	The measured surface is too far, outside the device's maximum measuring range (X_{max}). Set the far- end blocking (P05) to a larger value, or change the technology to ensure that the surface to be measured does not get so far from the sensor of the device.
11	—	_
12	One or more slave controller(s) failure! (Error)	One of the device's auxiliary controllers has failed. The probability of a firmware error is high. Performing a complete firmware update with NiFlash (including synchronization) may solve the problem. If unsuccessful, contact the dealership.
13	Relay failure (Error)	If the device has an optional relay, it is faulty. Contact the dealership.
14	Parameter table integrity error (Error)	The value of one or more parameters is not consistent with the associated parameters. Correct the parameter value.

Bit №	Device Specific Error/Warning flags	Meaning, possible reason, solution
15	Sensor failure (Error)	The radar sensor is faulty. There can be several reasons for this, e.g., the data connection with the radar sensor unit is inadequate or insufficient energy available for the measurement. The terminal voltage of the device must be above the prescribed minimum in all circumstances! Check the voltage conditions of the loop by measurement and change it as necessary so that the electrical conditions for the terminals of the device are met. Contact the dealership if the power supply voltage level is correct and the error persists.

Bit №	Device-Specific Status flags (DSS)	Explanation
0-2	PV value type	The type of the primary trapsmitted value (DV) by D01a
	(DIST, LEV, VOL, MASS, FLOW, LEV%, VOL%,)	The type of the philling transmitted value (1 v) by 1 ora.
3	Manual programming is active (Status)	The device is in manual programming mode.
		(Only on devices (WG□) featuring a display.)
4	Remote programming is active (Status)	The device is in remote programming mode.
5	Simulation is active (Marning)	The device is in simulation mode.
	Simulation is active (warning)	Caution! The output value is independent of the measured value.
6	User password is set (Status)	Password protection is active.
7	Relay energized (Status)	Relay is energized.
8	User lock is active (Status)	User lock is active. The parameters are protected by a password set by the user.
9	Factory lock is active (Status)	Factory lock is active. The factory default settings and calibration data are locked.
10	NRM-300P display is connected (Status)	A display is connected to the device. (Only on devices (WG□) featuring a display.)
11	Diagnostic mode is active (Status)	The device is in diagnostic mode.
12	HOLD (Warning)	The transmitted value is on hold.
13	Calibration mode is active (Status)	The device is in calibration mode.
14	Valid (Status)	The transmitted value is refreshed and valid.
15	HS communication mode is active (Status)	The device is in high-speed communication mode.

11.2Typical application errors

Error	Possible cause	Solution
The transmitted value takes a value from a close range (most often around 0.2 m).	Condensation or dirt on the antenna.	Clean the antenna or use a threshold mask to block the interfering echo.
The measured value does not change despite the level change.	This typically happens when echo loss occurs. In most cases, this is: – during foaming of the medium – dirt on the antenna – excessive waves – incorrect max. (P03) measurement setting – it can happen in cases of echo below the threshold curve.	Remove dirt from the antenna. Check the surface of the medium to be measured, if necessary, take measures to reduce foaming or ripples! Check threshold settings. See Chapter 12.3! Check the P03 maximum measuring distance setting.

12. NUS-NTB_NRM-SW Instructions

If necessary, install the NUS-NTB_NRM-SW HART configuration software (hereafter NUS-NTB_NRM-SW) as described in the program's manual. The software can be downloaded from www.Kobold.com.

Electrical connections: Start the program and search for the transmitter with the program (for more information, see also NUS-NTB_NRM-SW user manual).

From the devices found during the detection, select the device you want to configure or program and open the "device programming" window of the device (see the NUS-NTB_NRM-SW user manual). All the necessary parameters and function settings can be changed with NUS-NTB_NRM-SW. This chapter only describes the specific functions related to NRE-4/NRE-6s and two programming examples.

12.1 Device Status Window

To invoke the "Device Status Window" in NUS-NTB_NRM-SW, right-click on the device line in the "Device List" in the main window and select the "Show Device Status Window" menu item in the popup window. This window shows the status and error messages of the NRE-4/NRE-6. (See Chapter 11.1) The "Device Status Window" can also be summoned in the "Polling" window by activating the corresponding check box.

12.2 Echo Diagram (oscilloscope function)

Click the "Echo Diagram" button in NUS-NTB NRM-SW to display the device's Echo Diagram. A window called "Echo map" will appear. This diagram shows the reflection curve measured by the device. In addition, this window can be used to adjust the threshold level. To update the chart or read the data, press the "Refresh" button on the bottom line of the window (or press the F4 key).



After a successful reading, an echo graph similar to the attached "Echo Diagram" appears. The displayed information content can be selected in the legend. The "Echo list" displays the location and data of the echo peaks evaluated by the device, of which the selected level signal is marked with the inscription "Selected peak."

12.3 Threshold settings

The function is intended for advanced users. Incorrect setting may render the device unable to measure!

The purpose of the threshold value and the threshold line is to mask unwanted echoes from the measurement. Echo peaks below the threshold level are not taken into account in the evaluation. Setting the threshold may be necessary if the device selects the wrong echo peak as the level, for example because there is an interfering object in the path of the ultrasound during the measurement. Before changing the threshold curve, it is recommended to minimize interfering echoes by selecting the correct installation location of the device.

The threshold can be edited in the Echo diagram window of the NUS-NTB NRM-SW software. In addition, the height of the entire threshold can be adjusted in a simplified way with the P34 "Threshold offset" parameter among the measurement optimization parameters. The main threshold line is used to trace the general shape of the echo curve. Threshold highlights, also known as threshold masks, are available to mask interfering



echo peaks protruding from the curve.

The threshold editing mode can be activated either by selecting "Threshold Edit Enable" in the bottom menu bar or by selecting "Threshold settings" \rightarrow "Threshold Edit Enable" in the context menu that appears when clicking the right mouse button. In this case, the threshold editing function bar appears in the upper half of the window, and the editable points are marked red on the threshold curve. If no editable point is selected, the "Threshold offset" can be set in the function bar, so the height of the basic threshold curve consisting of three points is the same. If an editable point is selected by clicking the left mouse button, its position can also be altered separately.

Threshold points can also be moved with the mouse by clicking and holding the left mouse button over the selected point. The changes only take effect in the device after pressing the "Apply Threshold settings" button, which can also be found in the threshold editing function bar or the context menu. To display the evaluation corresponding to the new threshold, refresh the chart with the "Refresh" button in the bottom menu bar (or the F4 function key).

12.4Threshold mask

The "Threshold Mask" function masks an echo peak that interferes with the measurement. To do this, after pressing the "Add new threshold mask" button in the threshold editing function bar, click the left mouse button in the diagram over the position where you want to place the threshold highlight, or if using the context menu, click with the right mouse button on the desired position, then select the "Add new threshold mask" function. The position and width of the threshold mask can also be adjusted afterwards in the threshold editing function bar by selecting the center point of the highlight as described above. In the case of graphic editing, its position and height can be adjusted by dragging the center point, and its width can be adjusted by dragging the corner point. A total of 4 threshold highlights can be defined. If there are more interfering echoes than 4, it is better to choose another mounting position.



Caution! The "Cursor On" function does not provide an exact value. It only calculates the value of a given point based on the graphical representation.

The threshold highlight can be deleted by selecting its center point, or turning the "Enabled" switch off in the threshold editing function bar, or selecting the "Del current threshold mask" function in the context menu. Until the changes are applied to the device with the "Apply Threshold settings" function, it uses the previous (current) threshold settings, which can be read with the "Read Threshold settings" function. The factory default settings can be restored with the "Reset Threshold Settings" function.

12.5The output conversion table (OCT) – (NUS-NTB_NRM-SW OC-Table)

The output conversion table (OCT) is active if table correction is selected in parameter P40. See Chapters 10.7, 10.8, and 10.9. The OCT is filled in using the NUS-NTB_NRM-SW software. The conversion table is usually used for volume measurement but can also be used for weight or flow measurement.

This table assigns different output values to the measured levels. The value on the left is always the measured level (relative to the zero-level distance (P04) setting), and the value on the right is the output value for the particular level. The unit associated with the output value is determined by the setting of the "Output source" (P01, HART - PV) and "Output units" (P02) parameters.

The output value is determined by linear interpolation between two value pairs, so the accuracy of the conversion depends on the density of the associated value pairs. After the last pair of points, the output value is calculated by linear extrapolation. The maximum number of pairs is 100. More information:

- Each new level value entered must be greater than the previous one.
- Take heed that the units in the table are always interpreted by the device according to the currently set units of measure. Therefore, the OCT must always be filled in with values corresponding to the set units.
- Caution! When using the conversion table, the setting of the current output (P10/P11) is also interpreted according to the value range (and measurement unit) defined on the left side of the table. Accordingly, the appropriate setting of the P10/P11 parameters is recommended after uploading the table.
- If the conversion table is filled in incorrectly, the output (transmitted) value will not be correct either!

A user-defined conversion table (e.g., "level - volume") can be created using NUS-NTB_NRM-SW as follows:

To fill in or set the output conversion (OC) table of the device, go to the "Device Settings" \rightarrow "OC-Table" tab in NUS-NTB_NRM-SW. Upload or modify the table according to "NUS-NTB_NRM-SW Instructions for Use." If the appropriate changes have been made in the table and it has been filled in correctly, press the "Send" button on this page ("OC-Table" tab) on the right side under the "Get" button to download the table to the device.

In the following example, five-point programming is presented, example: "Level - Volume" conversion

Step	Action	Entered data / chosen value	
1	In NUS-NTB_NRM-SW, open the "Device Settings" window of the given device.		
2	Go to the point called "Application" and select the unit system ("Calculation system"). Metric (EU)		
3	Select a length unit (Engineering Unit).	m	
4	Go to "Measurement configuration" and select "Measurement mode (PV source): volume transmission" from the list.	Volume	
5	Select a volume unit in the "Volume Units" section.	m³	
6	Go to "Measuring distances" and enter the tank height in the field named "Zero-level dist." (Click on the field and enter the value).	6.00 m	
9	Press the "Send" button in the lower right corner of the window to download the new values to the device.	Wait until the download process is complete.	
10	Go to the point called "OC-Table." Fill in the table called "OCT list" with the appropriate values. A maximum of 100 points can be entered. Each level and volume point must be entered. Each subsequent point must be larger than the previous one. New lines can be created by pressing the "Ctrl + Insert" key combination or selecting "Add new item" in the popup menu of the right mouse button. A line can be deleted by pressing the "Ctrl + D" keys together.	See the following table (Example for completing OCT)	
11	To download the table to the device, press the "Send" button located on this page ("OC-Table" tab) on the right side under the "Get" button.		

Example of filling out the OCT

Point	Level (Source column)	Volume (Output column)
1	0.0 m (0.0 ft)	0.0 m³ (0.0 ft³)
2	0.20 m (0.66 ft)	0.5 m³ (17.6 ft³)
3	0.75 m (2.46 ft)	1.0 m ³ (35.3 ft ³)
4	1.00 m (3.30 ft)	1.5 m³ (53 ft³)
5	5.60 m (18.37 ft)	16.8 m ³ (593.3 ft ³)

Additional procedure for displaying 4...20 mA current output (using NUS-NTB_NRM-SW)

Step	Action	Entered data / value
1	Go to "Outputs" and set "Current generator mode" to "Auto" (default setting)	Auto
2	In the "Error indication" field, set the error status to the appropriate mode (default setting).	Hold-
3	Select "Assignment of 4 mA – PV (P10)" and enter the volume value corresponding to the output current value of 4 mA.	
4	Select "Assignment of 20 mA – PV (P11)" and enter the volume value corresponding to the output current value of 20 mA.	16.80 m ³ (593.3 ft ³)
5	Press the "Send" button in the lower right line of the window to download the new values to the device.	
6	Press the "X" close button to exit the device settings window.	

12.6Programming example 1 – configuring level measurement (using NUS-NTB_NRM-SW)

Configuring level measurement in a 9 m (29.5 ft) tank (example). Level measurement is the factory default mode, it is sufficient to enter only the actual tank height (P04 = 9.0 m [29.5 ft]). The max. measuring length of the NRE-4/NRE-6 radar configured by the manufacturer is 10.0 m (33 ft), so it covers the required 9 m (29.5 ft).

Step	Action	Entered data / value
1	Open the "Device Settings" window corresponding to the given device in NUS-NTB_NRM-	The program reads and displays the device settings.
2	Select "Measurement configuration."	
3	Click on "Zero-level dist." (Zero-level distance) field.	Data in the field: 10.000 [m] (33.000 [ft])
4	Enter the new value.	9,000 [m] (29.500 [ft])
5	Press the "Send" button in the lower right corner of the window to download the new value to the device.	The device will work according to the new settings after the download is complete.
6	Press the "X" close button to exit the device settings window.	

12.7 Programming example 2 – configuring the current loop output (using NUS-NTB_NRM-SW)

Custom scale setting: Example: 4 mA indicates the 1 m level [3.3 ft], 20 mA indicates the full tank, for example 8 m (26.2 ft) maximum level, upper error current. Set current range 4...20 mA with 22 mA error indication. Choose a suitable minimum and maximum value for the scale of the measurement.

Step	Action	Entered data / value
1	In NUS-NTB_NRM-SW, open the "Device Settings" window corresponding to the given device.	The program reads the device settings and displays them.
4	Select "Outputs"	
5	Select the "Error indication" drop-down list.	The field will read "Hold"
6	Select the new setting value (22 mA) in the drop-down list.	The field will read "22 mA"
7	Select the "Assignment of 4 mA – PV" data field.	The field will read "0.000 [m]" (0.000 [ft])
8	Enter the new value. This sets the level corresponding to the 4-mA minimum output (1 m).	The field will read "1.000 [m]" (3.300 [ft])
9	Select the "Assignment of 20 mA – PV" data field.	The field will show the maximum measuring distance by default.
10	Switch to 8.000 m (26.20 ft). This sets the level corresponding to the 20-mA maximum output (8 m [26.2 ft]).	The field will read "8.000 [m]" (26.20 [ft])
11	Press the "Send" button in the lower right line of the window to download the new values to the device.	After the download is complete, the device will use the new settings.
12	Press the "X" close button to exit the device settings window.	

13. Programming with NRM-300P Display Unit

The main parameters of NRE-4/NRE-6 can also be set using the NRM-300P display unit. By default, the display shows the primary measurement result (from which the output current is calculated). In addition to the measurement value displayed in large figures, a bar graph representing the output current value is also shown on the right. Programming is done via a text (E) () () () () () menu. Use the keys to navigate through the menu.

13.1NRM-300P display unit

Display: 64×128 dot matrix LCD, with symbols, units, and column diagram Ambient temperature: $-20...+65 \degree C (-4...+149 \degree F)$ Housing material: PBT fiberglass-reinforced plastic (DuPont[®])

The NRM-300P is a plug-in module with an LCD (universal – can be used in other KOBOLD devices, provided that the device's software supports NRM-300P).

Caution!

The NRM-300P is based on LCD technology, do not expose the NRM-300P to prolonged heat or sunlight as the display may be damaged.

If it is not possible to protect the NRE-4/NRE-6 from sunlight or if the NRE-4/NRE-6 is to be used outside the operating temperature range of the NRM-300P, do not leave the NRM-300P in the NRE-4/NRE-6!

13.2The NRE-4/NRE-6 during programming

By default, the NRE-4/NRE-6 displays the main measurement data on the NRM-300P display (hereafter referred to as the display). To enter the programming menu, (E) press the button. Use (\cdot) the buttons to navigate between the menu items.

You can also enter the selected menu item by pressing the E button. To return to the previous menu level, press the E button.

The buttons only work when the NRM-300P is present!

While using the menu, the instrument continues measuring without interruption. Any setting changes made in the menu will take effect when you exit the menu. If the NRE-4/NRE-6 menu is not exited, the NRE-4/NRE-6 will automatically return to the measurement display state after 30 minutes. Any changes made in the menu will then be ignored.

If the NRM-300P is unplugged from NRE-4/NRE-6, NRE-4/NRE-6 will automatically exit the menu and ignore any changes made to the menu. Since programming with the NRM-300P (manual programming) and remote programming via HART (REMOTE MODE) create a competing situation, only one mode can be used at a time.

Manual programming has priority!

During manual programming, the device sends a "device busy" signal to the HART master (HART Response code: 32 - Device is busy).

In remote programming mode, REM appears on the top right of the display. In this case, manual programming of the device is disabled, and the menu cannot be accessed.

If no NRM-300P is connected, the LEDs will become visible, the COM LED will flash to indicate HART communication, and the VALID LED will indicate if the data measured by the device is valid.

13.3 Manual programming

While on a submenu item, pressing the (E) button will change the parameter or access an additional submenu. There are two modes:

<u>Text list:</u> It can be navigated like the menu list. Accept selection by pressing and discard it by pressing the button.

<u>Editable number field:</u> It is used to edit numeric values. Editing is assisted by a cursor (inverse character). The number on the cursor position can be changed with the $: \odot / \odot$ keys (no over-, under-, or underflow between characters). The cursor can be moved to the left with the $: \odot$ arrow key (max. 9 characters space, including the decimal point). When you reach the end of the field, the cursor returns to the first position on the right. The modification is completed by (\boxdot)

pressing the button. NRE-4/NRE-6 will then check the value entered, and if it is not correct, the message "WRONG VALUE!" will appear on the bottom line.



14. Parameter list

Pr.	Page	Name		Value	1	Pr.	Page	Name		Va	llue	•
			d	сb	а				d	С	b	а
	20	Unit system, default unit, region parameter				P22	34	User Slope Correction Factor				
	22	Output source				P23		_				
	22	Output units				P24		_				
	24	Maximum sensing distance				P25	34	Echo selection				
	24	Zero-level distance (tank height – H)				P26	35	Level rise speed (filling speed)			Γ	
	26	Close-end blocking (dead-zone)				P27	35	Level drop speed (discharging speed)				
	26	Far-end blocking				P28	35	Measurement loss management				
		_				P29	36	Tank Full Limit				
	27	Manual output current value				P30		_			Γ	
		_				P31		_				
	27	Output value assigned to 4 mA				P32	36	Density of the measured medium				
	28	Output value assigned to 20 mA				P34	37	Threshold offset				
	28	Analog current loop output's mode				P36	37	BLE settings			Γ	
	30	Relay output				P40	38	Tank shape				
	31	Relay parameter – Trigger value				P41	42	Tank dimensions / Volume flow options				
	31	Relay parameter – Release value				P42	42	Tank dimensions / Flume – weir dimensions				
	32	Relay parameter – Delay				P43	42	Tank dimensions / Flume – weir dimensions			Γ	
	32	Relay parameter – Flow parameter value				P44	42	Tank dimensions / Flume – weir dimensions				
		_				P45	42	Tank dimensions / Flume – weir dimensions				
	32	HART address				P46	46	The distance to the surface without flow			Γ	
	32	Damping Time				P47	39	Total tank volume				
		_										

Pr.	Page	Name	Pr.	Page	Name
P60	48	Number of operating hours since issuing [h]	P80	48	Current generator calculated output current [mA]
P61	48	The number of operating hours since the last power-on [h]	P81	48	Status of relay outputs
P62	48	The number of operating hours of the signal detector (closed time of contact C2) [h]	P82		-
P63	48	The number of switching cycles of the relay	P83		_
P64	48	The current temperature of the electronics [°C / °F]	P84	49	Simulation method
P65	48	The highest temperature of the device ever measured [°C / °F]	P85	50	DIST simulation cycle time
P66	48	The lowest temperature of the device ever measured [°C / °F]	P86	50	Lower level of simulation
P67		_	P87	50	Top level of simulation
P68		_	P88	50	Total simulation time (timeout)
P69		_	P89		_
P70	48	Number of detected peaks (current)	P90		_
P71	48	Magnitude of selected echo [raw value]	P91		_
P72	48	Amplitude of selected echo [dB]	P92		_
P73	48	Distance of selected echo [m]	P93		_
P74	48	Echo lost / shot rate	P94	48	Software identifier (RADAR)
P75			P95	48	Software identifier (COPROC)
P76	48	Measuring height of the flow measurement (read only) (LEV)	P96	48	Software identifier (MAIN MCU)
P77	48	TOT1 totalizer (clearable)	P97	48	Special config mode (read only)
P78	48	TOT2 totalizer	P98	48	Hardware code (read only)
P79	48	Current generator re-measured output current [µA]	P99		

15. Maintenance, repair and storage conditions

NRE-4/NRE-6 devices do not require regular maintenance. There may be occasions when the sensor head has to be cleaned of deposits. Cleaning must be done carefully without scratching or indenting the radiating surface.

All repairs, whether in-warranty or out-of-warranty must only be done by KOBOLD. The device must be cleaned before it is returned for repair, all chemicals must be neutralized, and the device must be disinfected! In addition, the device must be accompanied by a "Statement of Safeness". In it, the person returning the device declares that the device is free from all contamination and hazardous substances. When not in use, the device must be stored within the ambient temperature specified in the technical data and at a maximum humidity of 98%.

16. Firmware update

The device's firmware is continuously maintained, considering user feedback and needs. If you want to update the firmware, contact your local KOBOLD partner!

17. Technical Information

Operating instructions, data sheet, approvals and further information via the QR code on the device or via <u>www.kobold.com</u>

18. Order Codes

Operating instructions, data sheet, approvals and further information via the QR code on the device or via <u>www.kobold.com</u>

19. Dimensions

Operating instructions, data sheet, approvals and further information via the QR code on the device or via <u>www.kobold.com</u>

20. Disposal

Note!

- Avoid environmental damage caused by media-contaminated parts.
- Dispose of the device and packaging in an environmentally friendly manner.
- Comply with applicable national and international disposal regulations and environmental regulations.

Batteries

Batteries containing pollutants are marked with a sign consisting of a crossed-out garbage can and the chemical symbol (Cd, Hg, Li or Pb) of the heavy metal that is decisive for the classification as containing pollutants:



- 1. "Cd" stands for cadmium
- 2. "Hg" stands for mercury
- 3. "Pb" stands for lead
- 4. "Li" stands for lithium

Electrical and electronic equipment



21. EU Declaration of Conformance

We, KOBOLD Messring GmbH, Nordring 22-24, 65719 Hofheim, Germany, declare under our sole responsibility that the product:

Non-contact Radar Level Transmitter, 80 GHz – Compact Design Model: NRE-4/NRE-6

to which this declaration relates is in conformity with the following EU directives stated below:

2014/30/EU	EMC Directive
2014/35/EU	Low Voltage Directive
2014/53/EU	RED
2011/65/EU	RoHS (category 9)
2015/863/EU	Delegated Directive (RoHS III)

Also, the following standards are fulfilled:

EN 61010-1:2010 + A1:2019 + A1:2019/AC:2019 Safety requirements for electrical equipment for measurement, control and laboratory use - Part 1: General requirements

EN 61326-1:2013 Electrical equipment for measurement, control and laboratory use - EMC requirements - Part 1: General requirements

EN 61326-2-3:2013 Electrical equipment for measurement, control and laboratory use - EMC requirements - Part 2-3: Particular requirements - Test configuration, operational conditions and performance criteria for transducers with integrated or remote signal conditioning

EN 302372:2017 Short Range Devices (SRD) - Tank Level Probing Radar (TLPR) operating in the frequency ranges 4,5 GHz to 7 GHz, 8,5 GHz to 10,6 GHz, 24,05 GHz to 27 GHz, 57 GHz to 64 GHz, 75 GHz to 85 GHz - Harmonised Standard covering the essential requirements of article 3.2 of the Directive 2014/53/EU

EN 302 729:2017 Short Range Devices (SRD); Level Probing Radar (LPR) equipment operating in the frequency ranges 6 GHz to 8,5 GHz, 24,05 GHz to 26,5 GHz, 57 GHz to 64 GHz, 75 GHz to 85 GHz; Harmonised Standard covering the essential requirements of article 3.2 of the Directive 2014/53/EU

EN 301489-1:2020 ElectroMagnetic Compatibility (EMC) standard for radio equipment and services - Part 1: Common technical requirements - Harmonised Standard for ElectroMagnetic Compatibility

EN 301489-33:2020 ElectroMagnetic Compatibility (EMC) standard for radio equipment and services - Part 33: Specific conditions for Ultra-WideBand (UWB) devices - Harmonised Standard covering the essential requirements of article 3.1(b) of Directive 2014/53/EU

Hofheim, 16 April 2024

H. Volz General Manager

J. Burke Compliance Manager

22. EU Declaration of Conformity (ATEX)

We, Kobold Messring GmbH, Nordring 22-24, 65719 Hofheim, Germany, hereby declare under our sole responsibility and with the aim of traceability that the product

Product type:	Non-contact Radar Level Transmitter, 80 GHz –
	Compact Design
	Type: NRE-4/NRE-6

EU type examination certificate: BKI24ATEX0011 X

Complies with all relevant requirements of the following directive(s):

2014/34/EU Equipment and Protective systems intended for use in potentially Explosive Atmospheres

The following harmonized standards were applied for conformity assessment:

EN IEC 60079-0:2018	Equipment – General requirements
EN 60079-11:2012	Device protection through intrinsic safety "i"

The above-mentioned product complies with Directive 2014/34/EU. New editions may have already replaced one or more of the standards mentioned in the EU type examination certificates. Kobold Messring declares that the product mentioned in this declaration of conformity either meets the requirements of the new editions or is not affected by the changes.

The notified body DEKRA Testing and Certification GmbH, identification number: 0158, was activated, in accordance with Article 17 of Directive 2014/34/EU, to monitor quality assurance related to the production process.

Hofheim, 01 July 2024

H. Volz General Manager

J. Burke Compliance Manager

23. Ex ia Certificate

	10 ID II			
		A NAH által akkreditált Product certifi by NAH und	NAH-6-0027/2022/K számon terméktanúsító szervezet. / cation organisation accredited er No. NAH-6-0027/2022/K	
	(1)	EU-Típus Vizsgálati EU-Tune Examinatio	Tanúsítvány n Certilicate	
	(2)	A potenciálisan robbanásveszélyes környezetb berendezések, védelmi re 2014/34/EU Direktív	en történő alkalmazásra szánt ndszerek a /	
		Equipment or Protective Systems in Potentially Explosive Atm Directive 2014/34/E	Intended for use lospheres U	
	(3)	EU-Típus Vizsgálati Tanúsítvány száma / EU-Type Examination Certificate number:	ATEX0011 X	
	(4)	A gyártmány / Product: NRE 80 GHz-es sugárzott mikrohullámú s NRE Non-contact radar level transmitter 8	zinttávadó / 0 GHz	
		Típusa / Type: NRE-7 integrált kivitelű típusváltozat, 8 NRE-4, -6 kompakt kivitelű típusváltoza Lásd részletes típusjelölést a 15.2 pontban / Se	0 GHz / integrated line t, 80 GHz / compact line e detailed type legend in point 19	5.2
	(5)	Gyártó / Manufacturer: Kobold Messring GmbH		
	(6)	Cím / Address: Nordring 22-24 65719 Hofheim am Taunus Germany		
	(7)	A gyártmány és annak változatai a jelen tanúsítvány vonatk This product and any acceptable variation thereto is specifie ments therein referred to.	ozó pontjában vannak feltüntetve. / d in the schedule to this certificate a	ind the docu-
	(8)	A ExVA Vizsgáló és Tanúsító Kft., 1418 sz. kijelölt testület, a 2014/34/EU Direktivájának 17. cikkelye szerint tanúsítja, ho ügyi és Biztonsági Követelményeknek a Direktíva II. számú térben alkalmazásra szánt gyártmányok tervezése és gyárta ExVA Testing and Certification Limited Liability Company, n ticle 17 of Directive 2014/34/EU of the European Parliame certifies that this product has been found to comply with the E to the design and construction of products intended for use in II to the Directive.	2014. február 26-i Európai Parlame gy a gyártmány megfelel az Alapve Mellékletében a potenciálisan robbar isa szerint. / otified body number 1418 in accorda nt and of the Council, dated 26 Fe issential Health and Safety Requiren potentially explosive atmospheres gi	nt és Tanács tö Egészség- násveszélyes ance with Ar- bruary 2014, nents relating ven in Annex
		A vizsgálat eredményeit az alábbi nyilvántartási számú bizalma talmazza: / The examination and test results are recorded in confidential re	s vizsgálati dokumentáció tar- vart No.:)021-24-A
	Ez a This	tanúsítvány csak a maga egészében és változatlan formában használható fe certificate may only be reproduced in its entirety and without any changes, s	el, mellékleteivel együtt. / Lapszá	im / Page:1/8
	Tanús	sítási eljárás 13. melléklete	Rev	00. 2023.02.01.
EXVA	410 UI Ü	ie we wie de we wie de in wie we we we we we we de de de die we we we de	en ma mo an an an an an an an an da an in an an an an an an	HI HI HI HI HI HI HI EXVA

	UN 10 UI		Ø					
EXVA	B	KI24ATEX0011 X	XVA					
	E	U-Típus Vizsgálati Tanúsítvány/						
11B	E	U-Type Examination Certificate	-					
	(9)	Az alapvető egészségügyi és biztonsági követelményeknek való megfelelést a következők biztosítják: / Compliance with the Essential Health and Safety Requirements has been assured by compliance with: MSZ EN IEC 60079-0:2018, MSZ EN 60079-11:2012						
		kivéve a 18. pontban felsorolt követelményekre vonatkozóan. except in respect of those requirements listed at item 18 of the Schedule.						
 (10) A tanúsítvány száma után álló "X" jel azt mutatja, hogy a gyártmány speciális feltételek megtartása melle meg a jelen tanúsítvány vonatkozó pontjában feltüntetett biztonságos alkalmazás feltételeinek. / If the sign "X" is placed after the certificate number, it indicates that the product is subject to Specific Con- of Use specified in the schedule to this certificate. 								
	 (11) Jelen EU-TÍPUS VIZSGÁLATI TANÚSÍTVÁNY csak a megjelölt gyártmány tervezésére és kivitelezésére vo natkozik. A jelen Direktíva további követelményei vonatkoznak a gyártmány gyártási folyamatára és szállítá sára. Ezek nem tartoznak e tanúsítvány alá. / This EU-TYPE EXAMINATION CERTIFICATE relates only to the design and construction of the specifie product. Further requirements of this Directive apply to the manufacturing process and supply of this product. These are not covered by this certificate. 							
	(12)	A gyártmány jele a következő / The marking of the product shall include the following: Lásd tanúsítvány 15.1 pontiát / See point 15.1 of certificate						
25								
83		ExVA Vizsgáló és Tanúsító Kft.	11					
5	EvV	A Vizegáló és Tanúsító Kft						
85	ExVA	A Testing and Certification Ltd.						
	Hung	gary, 1037 Budapest, Mikoviny u. 2-4. Nagy Botond						
213 275	Tel.:	+36 1 408 2213 Tanúsító Szervezet Vezető /						
	L-ma	Head of Certification Body	-					
65 65		Budapest, 2024. június / June 10.						
22 22								
55			-					
111			11					
II			=					
11			11					
11								
51 H			10					
53								
51			11					
11 11								
E B B B B B B B B B B B B B B B B B B B								
		X						
45.33	-							
	Ez a This	a tanúsítvány csak a maga egészében és változatlan formában használható fel, mellékleteivel együtt / Lapszám / Page: 2/8 a certificate may only be reproduced in its entirety and without any change, schedule included.						

	BKI24ATEX0011 X						
	EU-Típus Vizsgálat	ti Tanúsítvá	any/				
E	EU-Type Examination	ion Certifica	ate				
			(13) Melléklet	/ Schedu	e		
		(14) EU-T EU-	ÍPUSVIZSGÁLAT TYPE EXAMINAT BKI24ATE	I TANÚSÍTV ION CERTIF X0011 X	ÁNY szám / ICATE N ^o		
(15) Gvártmány leírása / Description of Product							
			factor and the A	مر مشرع الم	anakaanaan fak	utanan hullámú frak	
	ciamodulált radar (F	MCW).	frekvenciasavban (v	w-sav) mukou	Szakaszosan ion	ytonos nullantu liekt	/ei
	A szinttávadó anten függően a mérendő idejével proporciona	nájával kisug felszínről viss ális frekvenci	árzott frekvenciamo szaverődik. A vissza aeltolódásából szán	dulált hullám er verő felület táv nolja ki nagy p	nergiájának egy ré olságát az elektror oontossággal, maj	sze a mérendő anya nika a visszavert jel fu d távolság-, szint- v	igtó utá ag
	térfogatarányos jelle	é alakítja. A r	milliméterhullámú jel	terjedési sebe	ssége levegőben	, gázokban, vákuum	ba
	ben a mérési ponto	ozegnyomast osságot. A vis	sszaverődő milliméte	erhullámok iele	rőssége nagymér	tékben függ a mére	nd
	közeg dielektromos	állandójától	(DK ill. ɛr), ezért ettő	l függően csök	kenhet a gyakorla	tban elérhető maxim	náli
	niciostavoidag. I						
	The NRE level trans	smitter is an	intermittent continue	ous wave frequ	ency modulated (FMCW) radar opera	tin
	Depending on the n	naterial to be	e measured, part of t	the energy of t	he frequency-mod	dulated wave emitted	d b
	the antenna of the						
		level transmit	tter is reflected from	the surface to	be measured. Th	ne electronics calcula	ate
	the distance of the i	level transmit reflecting sur	tter is reflected from face from the freque	the surface to ency shift propo distance- leve	be measured. The prtional to the runn al- or volume-prop	ne electronics calculation ning time of the reflect portional signal. The	ate cte
	the distance of the r signal with high acc pagation speed of the	level transmit reflecting sur uracy, and th he millimeter	tter is reflected from face from the freque en converts it into a wave signal in air, g	the surface to ency shift propo distance-, leve jases, and vac	be measured. The ortional to the runn el-, or volume-prop uum is almost con	ne electronics calculation ning time of the reflect portional signal. The instant regardless of t	ate cte pro
	the distance of the isignal with high acc pagation speed of the perature and mediu	level transmit reflecting sur uracy, and th he millimeter im pressure,	tter is reflected from face from the freque en converts it into a wave signal in air, g so these factors do	the surface to ncy shift propo distance-, leve lases, and vac not significant	be measured. The pritonal to the runn el-, or volume-prop uum is almost con ily affect the meas	ne electronics calculation operational signal. The stant regardless of the surement accuracy.	ate cte pro em Th
	the distance of the is signal with high acc pagation speed of the perature and mediu signal strength of the of the medium to be	level transmit reflecting sur uracy, and th he millimeter im pressure, e reflected m measured, th	tter is reflected from face from the freque len converts it into a wave signal in air, g so these factors do illimeter waves depe erefore the maximu	the surface to ncy shift propo- distance-, leve jases, and vac- not significant ends to a large m measurement	be measured. The prional to the runn el-, or volume-prop uum is almost con dy affect the meas extent on the diele nt distance that cal	ne electronics calculating time of the reflect portional signal. The instant regardless of t surement accuracy. ectric constant (DK of n be achieved in prace	ate cte pro em Th r ɛi ctic
	the distance of the r signal with high acc pagation speed of the perature and mediu signal strength of the of the medium to be may decrease dependent	level transmit reflecting sur- uracy, and th he millimeter im pressure, e reflected m measured, th ending on this	tter is reflected from face from the freque ien converts it into a wave signal in air, g so these factors do illimeter waves depen- herefore the maximum 5.	the surface to ncy shift propo- distance-, leve asses, and vac- not significant ends to a large m measurement	be measured. The prional to the runn el-, or volume-propuum is almost con ally affect the mease extent on the dielect the distance that can	ne electronics calculating time of the reflect portional signal. The instant regardless of t surement accuracy. ectric constant (DK o n be achieved in prace	ate cte pro em Th r ɛi ctic
	the distance of the isignal with high acc pagation speed of the perature and mediu signal strength of the of the medium to be may decrease dependent	level transmit reflecting sur uracy, and th he millimeter um pressure, re reflected m measured, th ending on this	tter is reflected from face from the freque ien converts it into a wave signal in air, g so these factors do illimeter waves depen- herefore the maximum s.	the surface to ncy shift propo distance-, leve jases, and vac not significant ends to a large m measuremen	be measured. The ritional to the runn il-, or volume-prop uum is almost con ily affect the meas extent on the diele at distance that can	ne electronics calcula ning time of the reflect portional signal. The istant regardless of t surement accuracy. ectric constant (DK o n be achieved in prace	ate cte pro err Th r a ctic
15.1	the distance of the isignal with high acc pagation speed of the perature and mediu signal strength of th of the medium to be may decrease dependent Védelmi jel, környd	level transmit reflecting sur auracy, and th he millimeter im pressure, e reflected m measured, th ending on this ezeti hõmérs	tter is reflected from face from the freque ien converts it into a wave signal in air, g so these factors do illimeter waves depe- erefore the maximum s.	the surface to ncy shift propo distance-, leve jases, and vac not significant ends to a large m measuremen mark, ambient	be measured. The prional to the runn el-, or volume-propuum is almost con uum is almost con dy affect the meas extent on the diele the distance that can temperature	ne electronics calcula ning time of the reflect portional signal. The instant regardless of t surement accuracy. ectric constant (DK o in be achieved in prace	ate cte pro en Th r c ctic
15.1	the distance of the isignal with high acc pagation speed of the perature and mediu signal strength of the of the medium to be may decrease dependent Védelmi jel, környe	level transmit reflecting sur uracy, and th he millimeter um pressure, e reflected m measured, th ending on this ezeti hőmérs	tter is reflected from face from the freque ien converts it into a wave signal in air, g so these factors do illimeter waves dependent nerefore the maximum s. séklet / Protection r	the surface to ncy shift propo- distance-, leve ases, and vaci- not significant ends to a large m measuremen mark, ambient	be measured. The pritonal to the runn el-, or volume-propuum is almost con ally affect the measurement on the dielect at distance that can a temperature	ne electronics calcula ning time of the reflect portional signal. The instant regardless of t surement accuracy. ectric constant (DK o in be achieved in prace	ate cte pro err Th r εlic
15.1	the distance of the isignal with high acc pagation speed of the perature and mediu signal strength of the of the medium to be may decrease dependent Védelmi jel, környd	level transmit reflecting sur uracy, and th he millimeter um pressure, e reflected m measured, th ending on this ezeti hőmérs	tter is reflected from face from the freque ien converts it into a wave signal in air, g so these factors do illimeter waves dependent interefore the maximum seklet / Protection r	the surface to ncy shift propo- distance-, leve jases, and vaci not significant ends to a large m measurement mark, ambient standard design	be measured. The reliant to the runnels, or volume-propuum is almost con- ty affect the measured to the dielec- the distance that can temperature temperature tailor T5 Ga	ne electronics calcula ning time of the reflect portional signal. The istant regardless of the surement accuracy. ectric constant (DK o in be achieved in prace	ate cte pro Th r ɛ ctic
15.1	the distance of the isignal with high acc pagation speed of the perature and mediu signal strength of the of the medium to be may decrease dependent of the integrated NRE integrated NRE	level transmit reflecting sur reflecting sur uracy, and th he millimeter im pressure, re reflected m measured, th ending on this ezeti hõmérs -7	tter is reflected from face from the freque ien converts it into a wave signal in air, g so these factors do illimeter waves depen nerefore the maximum s. séklet / Protection r Normál kivitel / S NRE-7	the surface to ncy shift propo- distance-, leve jases, and vaci- not significant ends to a large m measurement mark, ambient tandard design II 1 G E II 1 D E	be measured. The retional to the runn ile, or volume-propuum is almost con- ity affect the measured extent on the dieled at distance that can temperature x ia IIC T5 Ga x ia IIIC T95°C Da	ne electronics calcula ning time of the reflect portional signal. The istant regardless of t surement accuracy. ectric constant (DK o in be achieved in prace	ate cte pro Th r ε ctic
15.1	the distance of the isignal with high acc pagation speed of the perature and mediu signal strength of the of the medium to be may decrease depe Védelmi jel, környd integrált NRE kompatt NRE4	evel transmit reflecting sur nuracy, and th he millimeter im pressure, e reflected m measured, th ending on this ezeti hőmérs	tter is reflected from face from the freque ien converts it into a wave signal in air, g so these factors do illimeter waves depe- nerefore the maximum s. séklet / Protection r Normál kivitel / S NRE-7 NRE-7	mark, ambient thandard design mark, ambient tandard design tandard design t	be measured. The price of volume-propuum is almost con- ity affect the measured the dielec- the distance that can temperature x ia IIC T5 Ga x ia IIC T95°C Da x ia IIC T6 Ga x ia IIC T85°C Da	ne electronics calcula ning time of the reflect portional signal. The instant regardless of t surement accuracy. ectric constant (DK o in be achieved in prace	ate cte pro Th Th r c tic
15.1	the distance of the isignal with high acc pagation speed of the perature and mediu signal strength of the of the medium to be may decrease depend Védelmi jel, környd integrált NRE integrated NRE kompakt NRE-4	evel transmit reflecting sur auracy, and th he millimeter im pressure, e reflected m measured, th ending on this ezeti hõmérs -7 -7 -7 -7 -7 -7 -7 -7 -7 -7 -7 -7 -7	tter is reflected from face from the freque ien converts it into a wave signal in air, g so these factors do illimeter waves depen- nerefore the maximum s. séklet / Protection r Normál kivitel / S NRE-7 NRE-4, -6 ömérsékletű kivitel	the surface to ncy shift propo distance-, leve jases, and vac not significant ends to a large m measuremen mark, ambient itandard design ill 1 G E ill 1 D E ill 1 D E ill 1 D E	be measured. The price of the runnels of the runne	ne electronics calcula ning time of the reflect portional signal. The istant regardless of t surement accuracy. ectric constant (DK o in be achieved in prace	The stic
15.1	the distance of the isignal with high acc pagation speed of the perature and mediu signal strength of the of the medium to be may decrease depe Védelmi jel, környd integrált NRE integrated NRE-4 kompakt NRE-4 kompakt NRE-4	level transmit reflecting sur uracy, and th he millimeter im pressure, e reflected m measured, th ending on this ezeti hőmérs -7 -7 -7 -7 -7 -7 -7 -7 -7 -7 -7 -7 -7	tter is reflected from face from the freque ien converts it into a wave signal in air, g so these factors do illimeter waves dependent nerefore the maximum s. séklet / Protection r Normál kivitel / S NRE-7 NRE-4, -6 5 mérsékletű kivitel NRE-4, -6	the surface to necy shift propo- distance-, leve asses, and vaci- not significant ends to a large m measuremen mark, ambient itandard design II 1 G E II 1 D E II 1 D E II 1 D E II 1 D E II 1 G E II 1 G E II 1 G E	be measured. The retional to the runnels, or volume-propuum is almost con- ty affect the measured extent on the dielect to distance that can take temperature take to the take to the take to the take to the take to the take to the take take to the take to the take to the take take to the take to the take to the take take to the take to the take to the take to the take take to the take to the take to the take to the take take to the take to the take to the take to the take to the take take take to the take to the take to the take to the take take take take to the take	a electronics calculating time of the reflectority of the reflectority of the reflectority of the reflectority of the surement accuracy. The surement accuracy is a curracy of the achieved in practice of the achieved of the achieve	ate cte pro Een Th r c ctic
15.1	the distance of the isignal with high acc pagation speed of the perature and mediu signal strength of the of the medium to be may decrease deperation of the integrated NRE integrated NRE kompakt NRE-4 compact NRE-4	level transmit reflecting sur nuracy, and th he millimeter im pressure, e reflected m measured, th ending on this ezeti hõmérs -7 -7 -7 -7 -7 -7 -7 -7 -7 -7 -7 -7 -7	tter is reflected from face from the freque ien converts it into a wave signal in air, g so these factors do illimeter waves depe- nerefore the maximum s. séklet / Protection r Normál kivitel / S NRE-7 NRE-4, -6 <u>5</u> MRE-4, -6	the surface to ncy shift propo- distance-, leve jases, and vaci- not significant ends to a large m measurement mark, ambient tandard design II 1 G E II 1 D E II 1 D E II 1 G E	be measured. The retional to the runne- ile, or volume-propuum is almost con- ity affect the measured extent on the dieled at distance that can temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature tempe	a a a a a a a a a a a a a a	ate cte pro Th r ɛ ctic
15.1	the distance of the isignal with high acc pagation speed of the perature and mediu signal strength of the of the medium to be may decrease depend Védelmi jel, környd integrált NRE integrated NRE kompakt NRE-4 compact NRE-4	evel transmit reflecting sur nuracy, and th he millimeter im pressure, e reflected m measured, th ending on this ezeti hőmérs -7 -7 -7 -7 -7 -7 -7 -7 -7 -7 -7 -7 -7	tter is reflected from face from the freque ien converts it into a wave signal in air, g so these factors do illimeter waves depe- nerefore the maximum s. séklet / Protection r Normál kivitel / S NRE-7 NRE-4, -6 5 MRE-4, -6	the surface to ncy shift propo- distance-, leve jases, and vaci- not significant ends to a large m measuremen mark, ambient standard design in 1 G E il 1 D E	be measured. The refined to the runnels, or volume-propuum is almost con- ity affect the measured the dielect the distance that can temperature temperature x ia IIC T5 Ga x ia IIC T5 Ga x ia IIC T6 Ga x ia IIC T6S°C Data x ia IIC T6S°C Data x ia IIC T6S°C Cata x ia IIC	a a a a a a a a a a a a a a	Th r sictic
15.1	the distance of the isignal with high acc pagation speed of the perature and mediu signal strength of the of the medium to be may decrease depend Védelmi jel, környd integrált NRE- kompakt NRE-4 kompakt NRE-4 compact NRE-4	evel transmit reflecting sur reuracy, and th he millimeter im pressure, e reflected m measured, th ending on this ezeti hõmérs -7 -7 -7 -7 -7 -7 -7 -7 -7 -7 -7 -7 -7	tter is reflected from face from the freque en converts it into a wave signal in air, g so these factors do illimeter waves depe- erefore the maximum s. séklet / Protection r Normál kivitel / S NRE-7 NRE-7 NRE-4, -6 5 MRE-4, -6	the surface to ncy shift propo- distance-, leve jases, and vaci- not significant ends to a large m measuremen mark, ambient itandard design ill 1 G E ill 1 D E	be measured. The price of volume-propuum is almost con- ity affect the measured. The the measured of the the the extent on the dieled the distance that can temperature temperature tailic T5 Ga x ia IIC T5 Ga x ia IIC T95°C Da x ia IIC T95°C Da the the the the the the the the temperature of the the the the the temperature of the the the the temperature of the the the the temperature of the the the the the temperature of the the the the the the temperature of the	a a f180°C Da	ate cte pro Th r c ctic
15.1	the distance of the isignal with high acc pagation speed of the perature and mediu signal strength of the of the medium to be may decrease depend Védelmi jel, környd integrált NRE-4 kompakt NRE-4 kompakt NRE-4 kompact NRE-4	evel transmir reflecting sur nuracy, and th he millimeter im pressure, e reflected m measured, th ending on this ezeti hőmérs -7 -7 -7 -7 -7 -7 -7 -7 -7 -7 -7 -7 -7	tter is reflected from face from the freque ien converts it into a wave signal in air, g so these factors do illimeter waves dependent illimeter waves dependent so séklet / Protection r Normál kivitel / S NRE-7 NRE-4, -6 5 MRE-4, -6 NRE-4, -6	the surface to ncy shift propo- distance-, leve jases, and vac not significant ends to a large m measuremen mark, ambient itandard design ill 1 G E ill 1 D E	be measured. The retional to the runnel- il-, or volume-propuum is almost con- ity affect the measured extent on the dielect at distance that can t temperature at in IIC T5 Ga x ia IIC T5 Ga x ia IIC T5 Ga x ia IIC T5 Ga x ia IIC T5 CDa x ia IIC T5	a a a a a a a a a a b a a a a b a c c b c c c c c c c c c c c c c	There are a contracted and a contracted
15.1	the distance of the isignal with high acc pagation speed of the perature and mediu signal strength of the of the medium to be may decrease depe Védelmi jel, környd integrált NRE- integrated NRE-4 compact NRE-4 integrált NRE-7 integrated NRE-7	level transmit reflecting sur reflecting sur in pressure, e reflected m measured, th ending on this ezeti hõmérs -7 -7 -7 -7 -7 -7 -7 -7 -7 -7 -7 -7 -7	tter is reflected from face from the freque ien converts it into a wave signal in air, g so these factors do illimeter waves depe- herefore the maximum s. séklet / Protection r Normál kivitel / S NRE-7 NRE-4, -6 Somérsékletű kivitel NRE-4, -6 Kijelző nélküli kivi In case of version wi	the surface to ncy shift propo- distance-, leve jases, and vaci- not significant ends to a large m measurement mark, ambient tandard design II 1 G E II 1 D E	be measured. The refional to the runne- il-, or volume-propuum is almost con- ity affect the measured. The extent on the dieled at distance that can the temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature	ne electronics calcula hing time of the reflect portional signal. The istant regardless of the surement accuracy. ectric constant (DK of in be achieved in prace a a a a r180°C Da ező kivítel esetén / ion with display	Th r sictic
15.1	the distance of the isignal with high acc pagation speed of the perature and mediu signal strength of the of the medium to be may decrease depe Védelmi jel, környd integrált NRE- integrált NRE-4 compact NRE-4,-6 compact NRE-4,-6	evel transmit reflecting sur nuracy, and th he millimeter im pressure, e reflected m measured, th ezeti hõmérs ezeti hõmérs -7 -7 -7 -7 -7 -7 -7 -7 -7 -7 -7 -7 -7	tter is reflected from face from the freque ien converts it into a wave signal in air, g so these factors do illimeter waves depe- nerefore the maximum s. séklet / Protection r NRE-7 NRE-7 NRE-7 NRE-7 NRE-4, -6 <u>Somérsékletű kivitel</u> NRE-4, -6 <u>Normál kivitel / S</u> Kijelző nélküli kivi In case of version w -40 °C +7	the surface to ncy shift propo- distance-, leve jases, and vaci- not significant ends to a large m measurement mark, ambient itandard design itandard design itandard design il 1 G E il 1 D E il 1 D E il 1 D E il 1 D E il 1 D E i	be measured. The retional to the runne- ile, or volume-propuum is almost con- ity affect the measured extent on the dieled at distance that can temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature tempe	e electronics calcula hing time of the reflect portional signal. The istant regardless of the surement accuracy. ectric constant (DK of in be achieved in prace a a a a a a a a a a a a a	There are
15.1	integrált NRE-4 kompakt NRE-4,-6 compact NRE-4,-6	evel transmit reflecting sur reflecting sur im pressure, e reflected m measured, th ending on this ezeti hõmérs -7 -7 -7 -7 -7 -7 -7 -7 -7 -7 -7 -7 -7	tter is reflected from face from the freque ien converts it into a wave signal in air, g so these factors do illimeter waves depe- nerefore the maximum s. séklet / Protection r Normál kivitel / S NRE-7 NRE-4, -6 5 MRE-4, -6 5 NRE-4, -6 5 NRE-4, -6 5 NRE-4, -6 5 NRE-4, -6 5 NRE-4, -6 5 Kijelző nélküli kivi In case of version w -40 °C +7 5 5 5	the surface to ncy shift propo- distance-, leve jases, and vaci- not significant ends to a large m measurement mark, ambient itandard design itandard design itandard design II 1 G E II 1 D E II 1 G E II 1 D E II 1 G E II 1 D E II 1 D E Standard design -40 °C. itel esetén / ithout display	be measured. The refional to the runne- ile, or volume-propuum is almost con- ity affect the measured extent on the dieledent to the distance that can the temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature	e electronics calcula hing time of the reflect portional signal. The istant regardless of the surement accuracy. ectric constant (DK of in be achieved in prace a a a a a a a a a a a a a	There are
15.1	the distance of the isignal with high acc pagation speed of the perature and mediu signal strength of the of the medium to be may decrease deperation of the medium to be integraft NRE- compact NRE-4.6	evel transmit reflecting surr nuracy, and th he millimeter im pressure, e reflected m measured, th ending on this ezeti hõmérs -7 -7 -7 -7 -7 -7 -7 -7 -7 -7 -7 -7 -7	tter is reflected from face from the freque en converts it into a wave signal in air, g so these factors do illimeter waves depen erefore the maximum 5. séklet / Protection r Normál kivitel / S NRE-7 NRE-4, -6 5 mérsékletű kivitel NRE-4, -6 5 Kijelző nélküli kivi In case of version w -40 °C +7 5 5 mérsékletű kivitel Kijelző nélküli kivi In case of version w	the surface to ncy shift propo- distance-, leve jases, and vaci- not significant ends to a large m measuremen mark, ambient itandard design itandard design il 1 G E il 1 D E il 1 D E	be measured. The prional to the runne- propuum is almost con- ty affect the mease extent on the dieled at distance that can temperature x ia IIC T5 Ga x ia IIC T5 Ga x ia IIC T6 Ga x ia IIC T6Ga x ia IIC T6S°C Da x ia IIC T6S°C Da x ia IIC T6S°C Ca x ia IIC Ca x ia IIC Ca x ia IIC Ca x ia IC Ca x ia IIC Ca x ia IC Ca	a a a a a a a a a a a a a a	ate cte prc Th r ει ctic
15.1	the distance of the isignal with high acc pagation speed of the perature and mediu signal strength of the of the medium to be may decrease deperation Védelmi jel, környd integrált NRE- integrált NRE-4 compact NRE-4 kompakt NRE-4,-6 compact NRE-4,-6 compact NRE-4,-6	level transmir reflecting sur reuracy, and th he millimeter im pressure, e reflected m measured, th ending on this ezeti hőmérs -7 -7 -7 -7 -7 -7 -7 -7 -7 -7 -7 -7 -7	tter is reflected from face from the freque en converts it into a wave signal in air, g so these factors do illimeter waves depei herefore the maximum s. séklet / Protection r NRE-7 NRE-7 NRE-7 NRE-7 NRE-4, -6 5 5 5 6 6 7 6 7 7 8 7 8 7 8 8 8 8 8 8 8 8 8 8	the surface to ncy shift propo- distance-, leve pases, and vaci- not significant ends to a large m measuremen mark, ambient itandard design itandard design II 1 G E II 1 D E Standard design -40 °C -40 °C 	be measured. The prional to the runne prional time temperature temperature temperature temperature temperature temperature temperature temperature temperature temperature transformation the time temperature te	a a a a a a a a a a a a a a	ate proceeding The The stic
15.1	the distance of the isignal with high acc pagation speed of the perature and mediu signal strength of the of the medium to be may decrease depend Védelmi jel, környd integrált NRE- integrált NRE-4 compact NRE-4 kompakt NRE-4 compact NRE-7 integrált NRE-7 integrált NRE-7 integrált NRE-7 integrált NRE-7 kompakt NRE-4,-6 compact NRE-4,-6	level transmir reflecting sur reuracy, and th he millimeter im pressure, e reflected m measured, th ending on this ezeti hõmérs -7 -7 -7 -7 -7 -7 -7 -7 -7 -7 -7 -7 -7	tter is reflected from face from the freque en converts it into a wave signal in air, g so these factors do illimeter waves depe- herefore the maximum s. séklet / Protection r NRE-7 NRE-7 NRE-7 NRE-7 NRE-4, -6 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5	the surface to ncy shift propo- distance-, leve pases, and vaci- not significant ends to a large m measuremen mark, ambient itandard design II 1 G E II 1 D E I II 1 D E I	be measured. The prional to the runne prional time prional temperature temperature temperature temperature temperature temperature temperature transformation to the runne temperature tempera	a a a a a a a a a a a a a a	ate: ctec pro m Thi r r r tic



RE-0 0 0 0 0 0				
- 111		 Opció / Option półkół / without 		Kód / Code
		neikui / without		10
111		Kimenet/Kijelz	ő/Védelem / Output/Display/Approval	Kód / Code
		4-20 mA HART	/ nélkül/without / ATEX Ex ia GD	A0I
111		4-20 mA HART	/ vele/with / ATEX Ex ia GD	A1I
		4-20 mA HART	+ Bluetooth / vele/with / ATEX Ex ia GD	B1I
		– Technológiai c	satlakozás / Process connection	AZ, AZ (0 AZ (0
		– Sugárzó és há	z anyaga /	Kód / Cod
		PP / PBT (inveg	na (Transducer) / Housing	P
		PP / Aluminium	and storated r grass and relindicedy	A
		PP / Rozsdame	ntes acél / Stainless steel	D
		1,4571 / PBT (0	vegszál erősítésű / glass fibre reinforced)	M
		1,4571 / Rozsd	amentes acél / Stainless steel	K
		PVDF / PBT (üv	regszál erősítésű / glass fibre reinforced)	V
		PVDF / Alumini	um (hiányos / painted)	B
		PTFE / PBT (üv	egszál erősítésű / glass fibre reinforced)	F
		PTFE / Alumini	um	Т
		PTFE / Rozsda	mentes acél / Stainless steel	L
		Kivitel / Versio	n (Design)	Kód / Cod
		Normál / Standa	ard	S
		Magas homerse	ekletů / High temperature	Н
		 Mérési távolsá 	g / Measuring range	AZ (0
		Típus / Type		
		sugárzott mikrol	ullámú szinttávadó, 80 GHz, kürt típus, kompa	kt vál- NRE-4
		sugárzott mikrol	nullámú szinttávadó, 80 GHz, tojás típus, komp	akt vál- NRE-6
		tozat / Radar Le	vel Transmitter, 80 GHz, egg type, compact ve	rsion
Műszak NRE-7 i Általáno	adatok / Tec ntegrált kivite os adatok / Ge	hnical data Iű típusváltozat eneral data	/ integrated design	
Ex jelölés	Ex marking (ATE	X)	🕞 II 1 G Ex ia IIC T5 Ga 😡	II 1 D Ex ia IIIC T95°C D
			Ui = 30 V, li = 100 mA, Pi = 0,75 W Ui =	30 V, li = 140 mA, Pi = 1
Ex tápegys Ex power s	eg gyűjtószikram supply, intrinsicsa	entes adatok / Ily safe data (*)	Gi ≤ 12 nF + 0,12 nF/m kábel / cable, Li ≤ 238 µ standard 5 m (16,4 láb) ká with standard cable 5 m (16,4 ft): Ci ≤ 1	.H + 0,65 μH/m kábei / ca beilel / 2,5 nF, Li ≤ 242 μH
Tápfeszült	ség / Supply volta	ge	1230 V DC	
And the second s	Imazácnál a IIIC	Ex tápogypág adat b	actrálandó / in IIP applications. Ex nower supply o	ata IIIC can be used

EXVA

BKI24ATEX0011 X EU-Típus Vizsgálati Tanúsítvány/

EU-Type Examination Certificate

Gyújtószikramentes (Ex ia) készülékek hőmérséklet határadatai / Temperature Limit Data for ATEX (Ex ia) Approved Models

Hőmérsékleti adatok / Temperature data	Robbanásveszélyes gáz atmoszféra / Hazardous gas atmosphere	Robbanásveszélyes poros atmoszféra Hazardous dust atmosphere		
	Ex ia IIC	Ex ia IIIC		
Hőmérsékleti osztály / Temperature class	T5	T95°C		
Legmagasabb környezeti hömérséklet / Highest ambient temperature	+80 °C (+176 °F)	+80 °C(+176 °F)		
Készülék legmagasabb felületi hőmérséklete / Highest surface temperature of the instrument (**)	+80 °C(+176 °F)	+80 °C(+176 °F)		

(**) Közeg, környezet vagy technológia csatlakozás által átadott vezetett vagy sugárzott hő következtében /

As a result of conducted or radiated heat transferred by medium, environment or technology connection /

NRE-4, -6 kompakt kivitelű típusváltozat / compact design

Általános adatok / General data

Alkalmazási cso	port / Application group	lic	IIIC	
Normál kivitel / Standard version Robbanásvédelmi jel / Ex marking (ATEX)		NRE-xxSxxxxA0	I / NRE-xxSxxxxA1I	
		😔 II 1G Ex ia IIC T6 Ga	ll 1D Ex ia IIIC T85°C Da	
Magas Hőmérsé	kletű kivitel / High Temperature version	NRE-xxHxxxxA0	I / NRE-xxHxxxxxA1I	
Robbanásvédelmi jel / Ex marking (ATEX)		😡 ll 1G Ex ia IIC T6T3 Ga	☺ II 1D Ex ia IIIC T85°CT180°C Da	
Ex tápegység gyújtószikramentes adatok / Ex power supply, intrinsicsally safe data (***)		Ui = 30 V, li = 100 mA, Pi = 0,75 W Ci ≤ 12 nF, Li ≤ 250 μH	Ui = 30 V, li = 140 mA, Pi = 1 W Ci ≤ 12 nF, Li ≤ 250 μH	
Tápfeszültség / S	upply voltage	1230V DC		
Elektromos	Kábel bevezető / Cable entry	M20x1,5 tömszelence / cable gland		
csatlakozás /	Kábel külső átmérő / Cable outer diameter	Ø 612 mm (Ø 0,250,5')		
Electrical connection	Vezetékér keresztmetszet / Wire cross section	0,51,5 mn	n² (AWG2015)	

(***) IIB alkalmazásnál, a IIIC Ex tápegység adat használandó / in IIB applications, Ex power supply data IIIC can be used

Gyújtószikramentes (Ex ia) készülékek hőmérséklet határadatai / Temperature Limit Data for ATEX (Ex ia) Approved Models

Hőmérsékleti adatok / Temperature data	Robbanásveszélyes gáz atmoszféra / Hazardous gas atmosphere NRE-4xSxxxxA0I / NRE-6xSxxxxA0I NRE-4xSxxxxA1I / NRE-6xSxxxxA1I Ex ia IIC, Ex ia IIIC	Robbanásveszélyes poros atmoszfé Hazardous dust atmosphere NRE-4xHxxxXA0/ / NRE-6xHxxxXA NRE-4xHxxXXA1/ / NRE-6xHxxXXA Ex ia IIC, Ex ia IIIC		atmoszféra / osphere oxHxxxxA01 oxHxxxxA11 IC
Hőmérsékleti osztály / Temperature class	T6 T85°C	T5 T100°C	T4 T135°C	T3 T180°C
Legmagasabb közeg hömérséklet / Highest process temperature	+80 °C (+176 °F)	+100 °C (+212 °F)	+135 °C (+275 °F)	+180 °C (+356 °F)
Legmagasabb felületi hömérséklet a technológiai csatlakozáson / Highest surface temperature at the process connection	+70 °C (+158 °F)	+100 °C (+212 °F)	+135 °C (+275 °F)	
Legmagasabb környezeti hőmérséklet / Highest ambient temperature	+70 °C (+158 °F)	+70 °C (+158 °F)	+60 °C (+140 °F)	

Ez a tanúsítvány csak a maga egészében és változatlan formában használható fel, mellékleteivel együtt. / This certificate may only be reproduced in its entirety and without any change, schedule included.

Lapszám / Page: 6/8

EXVA

			EXV
	EU-Típus Vizsgálati Tanúsítvány/ EU-Type Examination Certificate		
(16)	i) Jegyzőkönyv / Report №		
	VA-0021-24-A ATEX értékelő jelentés / assessment report	2024.06.10.	
(17)) Biztonságos üzemeltetés feltételei / Special conditions of Use		
	 A gyújtószikramentes eszközök csak a műszaki előírásoknak megfelelő, [lemmel tanúsított és jóváhagyott áramkörökröl üzemeltethetők. 	Ex ia IIC] vagy [Ex ia IIB] véde-	e,
	 Ha a készüléket túlfeszültségnek kitett helyre telepítik, a készüléket legala delemmel kell ellátni!. 	ább II. osztályú túlfeszültségvé-	1
	 A készülékház alumíniumötvözet-tartalma meghaladja a határértéket, ezé nyezetben a berendezést védeni kell az ütési és súrlódási hatásoktól. 	ert robbanásveszélyes (Ex) kör-	8
	 A készülék háza statikus töltést felhalmozni képes anyagból készült! Az szikraképződés és gyulladás veszélyét hordozza magában, ezért az elektro veszélyes (Ex) környezetben teljesen meg kell akadályozni! A készülék csak töltésátvitelt okozó közvetlen légáramtól és minden eg mentes környezetbe telepíthető. Kivéve, III. alkalmazás csoport esetén por vezetőképesége nagyobb mint >10⁻⁹ S (50±5% relatív nedvesség 	elektrosztatikus töltés jelenléte osztatikus feltöltődést robbanás- gyéb feltöltődést okozó hatástól abban az esetben, ha a szálló- mellett) illetve >10 ⁻¹¹ S (30±5%	1 2010 - 10 - 10 - 20 - 20
	 relatív nedvesség mellett). Fokozott óvatossággal kell eljárni karbantartás során, amikor is robbar a technológiai tartályban. A készüléket robbanásveszélyes (Ex) körny vízzel nedvesített antisztatikus törlőkendővel lehet! 	nóképes anyagmaradvány lehet yezetben megérinteni kizárólag	
	A fenti előírások betartása esetén a zárt technológiai rendszerre tekintettel sta sára nincs lehetőség, igy gyulladásveszély sem áll fenn. /	atikus feltöltődés felhalmozódá-	
	 Intrinsically safe devices can only be operated from circuits that comply will certified and approved as [Ex ia IIC] or [Ex ia IIB] protection. 	th the technical specifications,	
	 If the device is installed in a location exposed to overvoltage, the device m Class II overvoltage protection! 	ust be equipped with at least	
	 For installation in Zone 0 the aluminum alloy content in the device housing losive (Ex) environments, the equipment must be protected against impact 	exceeds the limit, so in exp- and friction effects.	
	 The housing of the device is made of a material capable of accumulating electrostatic charge poses a risk of spark generation and ignition, so elect completely prevented in explosive (Ex) environments! The device can only be installed in an environment free from direct air transfer and any other charging effects. Except for Group III application is greater than >10-9 S (at 50±5% relative humidity) or >10-11 S (at 30±0.1000) Increased caution is required during maintenance when explosive ma the technological tank. The device in explosive (Ex) environments car moistened antistatic wipe! 	static charge! The presence of trostatic charging must be r streams causing charge ons, where the dust conductivity £5% relative humidity). terial residue may be present in n only be touched with a water-	Ĩ
	In case of compliance with the above regulations, considering the closed techr possibility of static charge accumulation, therefore, there is no ignition hazard.	nological system, there is no	
Ez a This	: a tanúsítvány csak a maga egészében és változatlan formában használható fel, mellékleteivel együt is certificate may only be reproduced in its entirety and without any change, schedule included.	tt. / Lapszám / Page: 7/8	
XVA III III II			EX

11

BKI24ATEX0011 X

EU-Típus Vizsgálati Tanúsítvány/ EU-Type Examination Certificate

(18) Alapvető egészségügyi és biztonsági követelmények / Essential Health and Safety Requirements

Amellett, hogy az alapvető egészségügyi és biztonsági követelményeknek való megfelelést a 9. pontban felsorolt szabványok biztosítják, a következő megfontolások vonatkoznak a gyártmányra, melyek megfelelősége jegyzőkönyvben bizonyított:/

In addition to the Essential Health and Safety Requirements (EHSRs) covered by the standards listed at item 9, the following are considered relevant to this product, and conformity is demonstrated in the report:

Záradék / Clause	Tárgy / Subject	
Nem vonatkozik / Not applicable		

(19) Rajzok és dokumentációk / Drawings and Documents

Nr.	Megnevezés / Denomination	Szám / Number	Verzió / Rev	Dátum / Date	Lapszám / Page
1.	Műkődési előirások / Operating Instructions	NRE-4/NRE-6 K01/0324	-	2024.06.03.	52
2.	Műkődési előirások / Operating Instructions	NRE-7 K01/0424	-	2024.06.03.	48
3.	Ex-adattábla / Ex data plate (NRE-4/NRE-6)	003.998	-	2024.04.02.	1
4.	Ex-adattábla / Ex data plate (NRE-7)	003.999	-	2024.04.02.	1

ExVA Vizsgáló és Tanúsító Kft. 1037 Budapest, Mikoviny S. u. 2-4 10925306-2-41

EXVA

Nagy Botond Tanúsító Szervezet Vezető / Head of Certification Body

Ez a tanúsítvány csak a maga egészében és változatlan formában használható fel, mellékleteivel együtt. / This certificate may only be reproduced in its entirety and without any change, schedule included.

Lapszám / Page: 8/8